

#### ARE SOCKETS SUPPLIED WITH YOUR VDM-1?

Not if you purchased your kit before May 1, 1976\*. Kits purchased before this date are shipped with one socket only, and that socket is for the character generator (IC4).

A set of sockets for the VDM-1 is available from Processor Technology for \$19.00, postpaid to U.S. and Canada if full payment accompanies your order. The added convenience in assembly and IC replacement is well worth the added investment in your VDM-1.

If you purchased your kit before May 1 and intend to install sockets for all ICs, follow the assembly procedure given in this manual.

If you do not intend to install sockets for all ICs, replace Step 1 in the procedure with the following.

( ) <u>Step 1</u>. Install 24-pin socket in Area A-6,7 for IC4. Avoid creating solder bridges between pins and traces.

Also, refer to "Loading DIP Devices" in Appendix III of this manual when performing Step 16, 18, 20 and 22.  $^{\circ}$ 

\*Sockets are included in all VDM-1 kits purchased after May 1, 1976 at the new kit price of \$179.00.

April, 1976

PROCESSOR TECHNOLOGY CORPORATION 6200 HOLLIS STREET EMERYVILLE CA 94608 (415) 652-8080 CABLE ADDRESS "PROCTEC"



## VDM - 1 ENGINEERING MODIFICATION (PC board rev. A through D)

A modification has been made to the circuit of the VDM-1 which will improve the timing margins in the vertical scrolling circuit. In order to incorporate these design changes in your unit, please carry out the following step before starting step 1 of the assembly instructions:

 On top side of board cut trace connecting pin 1 of IC 13 with pin 15 of IC 13.

Now proceed with assembly until you reach step 15. After completing step 15, carry out the following steps before continuing with step 16:

- 2. Cut trace from pin 2 of IC 19 to R 18.
- 3. Connect a jumper wire from R 18 to pin 7 of IC 13.
- 4. Cut trace from pin 1 of IC 13 to R 13.
- 5. Connect a jumper wire from pin 1 of IC 13 to pin 10 of IC 15.
- 6. Connect a jumper wire from pin 15 of IC 13 to pin 5 of IC 13.

0000000 (TOP SIDE)

0000000 (TOP SIDE)

0000000 (TOP SIDE)

BOTTOM SIDE OF BOARD SHOWN

TOP EDGE OF BOARD

PROCESSOR TECHNOLOGY CORPORATION 6200 HOLLIS STREET EMERYVILLE CA 94608 (415) 652-8080 CABLE ADDRESS "PROCTEC"

ADW-T A	IDEO	DISPLAY MODULE	CONTENTS
SECTION	[	TITLE	PAGE
I	INTF	RODUCTION and GENERAL INFORMATION	
	1.1	Introduction	. I-1
	1.2	General Information	. I-1
		1.2.1 VDM-1 Description	. I-1 . I-2 . I-2 . I-2
II	ASSE	MBLY and TEST	
	2.1	Assembly Tips	. II-1
	2.2	Assembly Precautions	. II-1
		2.2.1 Handling MOS Integrated Circuits 2.2.2 Soldering	
	2.3	Required Tools, Equipment and Materials	. II-2
	2.4	Parts and Components	. II-3
	2.5	Orientation	. II-3
	2.6	Assembly-Test Procedures	. II-3
	2.7	Final Test Procedures	. II-21
		2.7.1 VDM-1 DIP Switch Settings	. II-21 . II-21 . II-22 . II-22 . II-23 . II-26
III	THEO	RY OF OPERATION	
	3.1	Theory of Operation	. III-l
		3.1.3 Screen Memory 3.1.4 Character Generation 3.1.5 Cursor Circuit 3.1.6 Video Circuit 3.1.7 Scroll Circuit 3.1.8 Computer Interface	. III-1 . III-2 . III-4 . III-4 . III-5 . III-6 . III-7
	3.2	Switch Selectable Options	. III-9

# VDM-1 VIDEO DISPLAY MODULE

CONTENTS

~	F.C	700	т	2	NT

TITLE

IV

DRAWINGS

VDM-l Assembly Drawing
VDM-l Schematic Diagram

## APPENDICES

I Statement of Warranty

II 8080 Operating Code

III Loading DIP Devices and Soldering Tips

IV Integrated Circuit Pin Configurations

V VDM-1 Terminal Software

VI Television Interface

# SECTION I

# INTRODUCTION and GENERAL INFORMATION

VDM-1 VIDEO DISPLAY MODULE



#### 1.1 INTRODUCTION

This manual supplies the information needed to assemble, test and use the VDM-l Video Display Module. We suggest that you first scan the entire manual before starting assembly. Then make sure you have all the parts and components listed in the "Parts List" (Table 2-1) in Section II. When assembling the module, follow the instructions in the order given.

Should you encounter any problem during assembly, call on us for help if necessary. If your completed module does not work properly, recheck your assembly step by step. Most problems stem from backward installed components and/or installing the wrong component. Once you are satisfied that the module is correctly assembled, feel free to ask for our help.

#### 1.2 GENERAL INFORMATION

# 1.2.1 VDM-1 Description

The VDM-l Video Display Module is not a limited "TV Typewriter". It is an ultra-high speed computer terminal designed to operate within your Altair.

This display module generates sixteen 64 character lines from data stored in a 1024 8-bit byte on-card RAM memory (random access memory). Alphanumeric and control characters (the full 128 upper and lower case plus control ASCII character set) are displayed in a 7 x 9 dot matrix. With its EIA video output, the VDM-1 can be used with any standard video monitor. (A TV set can also be easily modified for use with the VDM-1. See Appendix VI.)

A two-port memory permits random read-write access to the screen memory from the memory bus of the CPU. Other features include:

- Normal (white-on-black background) video display or inverted (black-on-white background) video display, switchselectable for entire screen or program-controlled for each character.
- 2. Video inversion block cursor, switch-selectable blink capability, programmable for each character location.
- Continuously adjustable display position, both vertical and horizontal.
- Text blanking (switch selectable) from CR control character to end of line and from VT control character to end of screen, excluding CR or VT character.

#### VDM-1 VIDEO DISPLAY MODULE

- Optional blanking of all control characters (switch selectable).
- Program-controlled scrolling of display in increments of one to 16 lines without rewriting memory.
- "Window shade" blanking of text above desired starting location, program controllable.
- 8. Scroll timer on board available for test by processor.

#### 1.2.2 Receiving Inspection

When your module arrives, examine the shipping container for signs of possible damage to the contents during transit. Then inspect the contents for damage. (We suggest you save the shipping materials for use in returning the module to Processor Technology should it become necessary to do so.) If your VDM-1 kit is damaged, please write us at once describing the condition so that we can take appropriate action.

#### 1.2.3 Warranty Information

In brief, the parts supplied with the module, as well as the assembled module, are warranted against defects in materials and workmanship for a period of 6 months after the date of purchase. Refer to Appendix I for the complete "Statement of Warranty".

## 1.2.4 Replacement Parts

Order replacement parts by component nomenclature (e.g. DM8131) and/or a complete description (e.g., 6.8 ohm,  $\frac{1}{2}$  watt, 5% resistor).

## 1.2.5 Factory Service

In addition to in-warranty service, Processor Technology also provides factory repair service on out-of-warranty products. Before returning the module to Processor Technology, first obtain authorization to do so by writing us a letter describing the problem. After you receive our authorization to return the module, proceed as follows:

- 1. Write a description of the problem.
- Pack the module with the description in a container suitable to the method of shipment.
- Ship prepaid to Processor Technology, 6200 Hollis Street, Emeryville, CA 94608.

Your module will be repaired as soon as possible after receipt and return shipped to you prepaid.

SECTION II

ASSEMBLY

and

TEST

VDM-1 VIDEO DISPLAY MODULE



#### 2.1 ASSEMBLY TIPS

- l. Scan Section II in its entirety before you start to assemble the VDM-l.
- 2. In assembling your VDM-1, you will be following an integrated assembly-test procedure. Such a procedure is designed to progressively insure that individual sections of the module are operating correctly. IT IS IMPORTANT THAT YOU FOLLOW THE STEP-BY-STEP INSTRUCTIONS IN THE ORDER GIVEN.
- 3. Assembly steps and component installations are preceded by a set of parentheses. Check off each installation and step as you complete them. This will minimize the chances of omitting a step or component.
- 4. When installing components, make use of the assembly aids that are incorporated on the VDM-1 PC board and the assembly drawing: (These aids are designed to assist you in correctly installing the components.)
  - a. The circuit reference (R3, Cl0 and IC20, for example) for each component is silk screened on the PC board near the location of its installation.
  - b. An alphanumeric "grid", that divides the board into 90 areas, is also silk screened on the PC board. (In the assembly instructions, grid coordinates are used to define the areas in which specific components are located.)
  - c. Both the circuit reference and value or nomenclature (1.5K and 7406, for example) for each component are included on the assembly drawing near the location of its installation.
- 5. To simplify reading resistor values after installation, install resistors so that the color codes read from left-to-right and top-to-bottom as appropriate (board oriented as defined in Paragraph 2.5).
  - 6. Install disc capacitors as close to the board as possible.
- 7. Should you encounter any problem during assembly, call on us for help if needed.

#### 2.2 ASSEMBLY PRECAUTIONS

## 2.2.1 Handling MOS Integrated Circuits

Several MOS integrated circuits are used in the VDM-1, and they can be damaged by static electricity discharge. Always handle

 $\dot{M}$ OS ICs so that  $\underline{no}$   $\underline{discharge}$  will flow  $\underline{through}$  the IC. Also, avoid unnecessary handling and wear cotton--rather than synthetic--clothing when handling these ICs.

#### 2.2.2 Soldering

- 1. Use a low-wattage iron, 25 watts maximum.
- 2. Solder neatly and quickly as possible.
- 3. DO NOT press top of iron on pad or trace. To do so can cause the pad or trace to "lift" off the board and permanently damage it.
- 4. Use only 60-40 rosin-core solder. NEVER use acid-core solder or externally applied fluxes.
- 5. The VDM-1 uses a circuit board with plated-through holes. Solder flow through to the component side of the board can produce solder bridges. Check for such bridges after each installation.
- 6. The VDM-1 circuit board has an integral solder mask (green lacquer) that shields selected areas on the board. This mask minimizes the chances of creating solder shorts during assembly.
- 7. Additional pointers on soldering are provided in Appendix III of this manual.
- 2.2.3 Installing and Removing VDM-1

NEVER install the VDM-l in, or remove it from, the computer with the power on. To do otherwise can damage the board.

2.2.4 Installing and Removing Integrated Circuits

NEVER install or remove integrated circuits with power applied to the  $\ensuremath{\text{VDM-1}}$  .

2.3 REQUIRED TOOLS, EQUIPMENT AND MATERIALS

- 1. Needle nose pliers
- 2. Diagonal cutters
- 3. Controlled heat soldering iron, 25 watts
- Sharp knife
- 5. 60-40 rosin-core solder (supplied)


Revision C Boards: Ignore Step 2, section 2.6 (page II-3), and instead follow these instructions when installing C 34 on page II-8:

①



SCRAPE SOLDER MASK (GREEN LACQUER)
FROM +5V TRACE AT C 34 (F2 CO-ORDINATE)

0



BUTTO


BEND LEADS OF QI (2N2907) AS INDICATED

3




ATTACH C AND E LEADS OF Q1 TO C34 AS SHOWN.

4



INSTALL C34 AND Q1 AS SHOWN. SOLDER B

SCHEMATIC:





#### VDM-1 VIDEO DISPLAY MODULE

- 6. Volt-ohm meter
- 7. Oscilloscope (optional)
- 8. IC test clip (optional)

#### 2.4 PARTS AND COMPONENTS

Check all parts and components against the "Parts List" (Table 2-1). If you have difficulty in identifying any parts by sight, refer to Figure 2-1.

#### 2.5 ORIENTATION

The heat sink area (large foil area) will be located in the upper righthand corner of the board when the edge connector is positioned at the bottom of the board. In this position, the component (front) side of the board is facing up. Subsequent position references assume this orientation.

#### 2.6 ASSEMBLY-TEST PROCEDURE

Refer to assembly drawing in Section IV.

#### CAUTION

THIS DEVICE USES SEVERAL MOS INTEGRATED CIRCUITS WHICH CAN BE DAMAGED BY STATIC ELECTRICITY DISCHARGES. HANDLE MOS IC SO THAT NO DISCHARGE FLOWS THROUGH THE IC. AVOID UNNECESSARY HANDLING AND WEAR COTTON, RATHER THAN SYNTHETIC, CLOTHING WHEN HANDLING THESE ICs.

- ( ) <u>Step l</u>. Install sockets in locations ICl through IC48. Each socket should be installed with its end notch oriented as indicated on the assembly drawing. Avoid creating solder bridges between pins and traces.
- () <u>Step 2</u>. Install Ql (2N2907) in Area G-2. The emitter lead (closest to tab on can) is oriented toward top of board and the base lead to the left. Push straight down on transistor until it is stopped by the leads. Solder and trim.
- ( ) <u>Step 3</u>. Install all resistors in numerical order in the indicated locations. Bend leads to fit distance between mounting holes, insert, pull down snug to board, bend leads outward on solder (back) side of board, solder and trim.

Refer to footnotes at the end of this step before installing flagged (\*, \*\*, #, ##, @ or @@) resistors.

# VDM-1 VIDEO DISPLAY MODULE

SECTION II

Table 2-1. VDM-1 Video Display Module Parts List.

	Display Module Parts Dist.
INTEGRATED CIRCUITS	
1 4001 (IC30) 1 7406 (IC1)	4 74Ls163 (IC2,20,21,22)
2 4029 (IC26,27) 2 74LS08 (IC	233,34) 1 74166 (IC3)
2 4042 (IC31,32) 2 74LS10 (IC	29,40) 3 74LS175 (IC5,6,17)
1 4049 (IC25) 1 74LS20 (IC	2 8097 or 8T97 (IC38,39)
1 MCM6574,6575 or 1 74LS86 (IC	1 8131 (IC29)
6576 (IC4) 3 74LS109 (I	[C10,13,16) 1 8836 or 8T380 (IC37)
2 74LS00 (IC15,35) 1 74LS132 (I	
1 74LS02 (IC14) 1 74LS138 (1	through IC48) 1 93L16 (IC8)
2 74LS04 (IC19,36) 3 74LS157 (1	(C23,24,28) 1 93L16 (1C8)
REGULATORS TRANSISTORS	DIODES CRYSTALS
1 340T-5.0V or 1 2N2907 (Q1)	1 ln5225B (D1) 1 HC-18/U (Y1),
7805UC (IC49)	2 lN4148 (D2,3) 13.478 MHz
1 78L12A (IC50)	
RESISTORS	CAPACITORS
1 75 ohm, ¼ watt, 5%	l 10 pfd, disc
2 200 ohm, ½ watt, 5%	l 680 pfd, disc
2 330 ohm, ½ watt, 5%	3 .001 ufd, disc
1 330 ohm, ½ watt, 5%	l .001 ufd, mylar
1 680 ohm, ½ watt, 5%	l .01 ufd, mylar
5 8.2K ohm, ½ watt, 5%	l .l ufd, mylar
3 39 K ohm, ½ watt, 5%	31 .1 ufd, disc
2 50 K ohm potentiometers	4 l ufd, tantalum
1 100 K ohm, ½ watt, 5%	l 15 ufd, tantalum
31 1.5K ohm, ½ watt, 5%	1 100 ufd, 15V, electrolytic
2 3.3M ohm, ¼ watt, 5%	
MISCELLANEOUS	
l VDM-l PC Board	l Tie Wrap
l Heat Sink	l Length Spaghetti
48 DIP Sockets	3 6-32 Screws
l DIP Switch, 6 or 7 posit	ion 3 6-32 Lockwashers
l Length #24 Bare Wire	3 6-32 Nuts
9" 8-conductor Ribbon Cable	l Length Solder
l Length 72-ohm Coaxial Ca	ble l Manual

# VDM-1 VIDEO DISPLAY MODULE

SECTION II




Figure 2-1. Identification of components.

VDM-1 VIDEO DISPLAY MODULE

SECTION II

LOCATION	AREA	VALUE (OHMS)	COLOR CODE
( ) R1* ( ) R2* ( ) R3* ( ) R4** ( ) R5+	A-1 A-1 A-2 A-3 A-4	75 330 ½ watt 200 1.5 K 1.5 K	violet-green-black orange-orange-brown red-black-brown brown-green-red
( ) R6 ( ) R7+ ( ) R8 ( ) R9 ( ) R10	A-10 B-2 B-2 B-4 B-4	680 ½ watt 1.5 K 39 K 1.5 K 1.5 K	blue-grey-brown brown-green-red orange-white-orange brown-green-red
( ) R11 ( ) R12 ( ) R13 ( ) R14 ( ) R15	B-5,6 B-10 C-3,4 C-4	200 1.5 K 1.5 K 1.5 K	red-black-brown brown-green-red
( ) R15 ( ) R16* ( ) R17* ( ) R18 ( ) R19+	C-6,7 D-3 D-3 D-3,4	1.5 K 330 330	orange-orange-brown "" brown-green-red
( ) R19+ ( ) R20 ( ) R21 ( ) R22 ( ) R23	D-4 D-6 E-1,2 E-1,2 E-1,2	1.5 K 1.5 K 3.3 M 8.2 K 100 K	" " " orange-orange-green grey-red-red
( ) R23 ( ) R24 ( ) R25 ( ) R26+ ( ) R27-32#	E-1,2 E-3 E-4 E-5 E-7,8	100 K 3.3 M 1.5 K 1.5 K	brown-black-yellow orange-orange-green brown-green-red
( ) R33## ( ) R34* ( ) R35 ( ) R36@	F-1 F-2 F-2 F-1,2	50 K 8.2 K 8.2 K 1.5 K	Potentiometer grey-red-red " " brown-green-red
( ) R37 ( ) R38 ( ) R39 ( ) R40+	F-2 F-2,3 F-3 F-5	39 K 8.2 K 39 K 1.5 K	orange-white-orange grey-red-red orange-white-orange brown-green-red
( ) R41-48@@ ( ) R49 ( ) R50## ( ) R51*	F-7 F-9 G-1 G-2	1.5 K 1.5 K 50 K 8.2 K	Potentiometer grey-red-red
		NOTE	

Unless noted otherwise, all resistors are  $\frac{1}{4}$  watt, 5%.

- \* Check for solder bridges to ground plane.
- Move R4 away from ICl (Area A-2,3) toward IC2 (Area A-3,4) before soldering.
- + Be sure leads do not short traces beneath them.

#### VDM-1 VIDEO DISPLAY MODULE

SECTION II

- # Leads at bottom of board (toward edge connector) must not short to one another.
- ## Install parallel to board with thumb wheels at top edge of board. Check for solder bridges to ground plane after installation.
- @ Take care that R35 and R36 leads do not short.
- @@ Check for solder bridges after installation.
  - ( ) <u>Step 4</u>. Install all capacitors in numerical order. Insert, pull down snug to board, bend leads outward on solder (back) side of board, solder and trim.

#### NOTE

Disc capacitor leads are usually coated with wax during the manufacturing process. After inserting leads through the mounting holes, remove the capacitor and clear the holes of any wax. Reinsert and install.

Refer to footnotes at the end of this step before installing flagged (\*, \*\*, @, @@, # or ##) capacitors.

LOCATION	AREA	VALUE (UFD)	$\underline{\mathtt{TYPE}}$
( ) C1* ( ) C2 ( ) C3 ( ) C4 ( ) C5 ( ) C6 ( ) C7* ( ) C8* ( ) C9* ( ) C10 ( ) C11 ( ) C12 ( ) C13 ( ) C14 ( ) C15 ( ) C16 ( ) C17 ( ) C18 ( ) C19 ( ) C20 ( ) C21** ( ) C22@ ( ) C23 ( ) C24	A-1,2 A-2,3 A-2,3 A-7 A-8 A-8 A-9,10 B-1 B-5 B-8 B-10 C-2 C-4 C-5 C-9 D-1 D-2 D-2 D-2 D-3 D-4 D-5 D-9	100 .1 .1 .1 .1 .1 .1 .1 .1 .1 .1 .1 .1 .1	Electrolytic Disc Disc Disc Disc Tantalum, dipped Tantalum, dipped Tantalum, dipped Tolsc Disc Disc Disc Disc Disc Disc Disc Di

	LO	CATION	AREA	VALUE (UFD)	TYPE
(	)	C25@@ C26	E-1,2 E-7	.01 .1	Mylar tubular Disc
(	)	C27#	F-2	.001	Mylar tubular
(	)	C28##	F-2	.001	Disc
	,	C29##	F-3	680 pfd	Disc
}	1	C30 C31	F-3,4 . F-4	.001 .1	Disc Mylar tubular
ì	1	C32	F-6	.1	Disc
ì	í	C33	F-9	.1	Disc
ì	í	C34	G-2	.1	Disc
Ì	ý	C35	G-4	.1	Disc
(	)	C36	G-5	.1	Disc
(	)	C37	G-9	.1	Disc
(	)	C38	G-10	.1	Disc
(	)	C39*, **	H-1	15	Tantalum, dipped
(	)	C40	H-1	.1	Disc
(	)	C41*, **	H-2	1	Tantalum, dipped
(	)	C42	J-5	.1	Disc
(	)	C43	J <b>-</b> 7	.1	Disc
(	)	C44	J <b>-</b> 8	.1	Disc
(	)	C45	J <b>-</b> 9	.1	Disc

- \* Take care to observe polarity.
- \*\* Check for solder bridges to ground plane.
- @ Check that C22 lead doesn't short to R19 (Area D-4). Move R19 lead as required.
- @@ Do not center C25 between mounting holes. Position it so the capacitor is closer to the top mounting hole and the resulting longer lead at the bottom end.
- # Check that C27 lead doesn't short to R36 (Area F-1,2). Move R36 lead as required.
- ## Be careful not to interchange C28 and C29.
  - ( ) <u>Step 5</u>. Install diode Dl (lN5225B) in Area A-10. Position Dl so that its band mark (cathode) is on the righthand side. Solder and trim leads.
  - ( ) <u>Step 6</u>. Install diodes D2 and D3 (lN4148) in Area E-1,2. Position these diodes with the band mark (cathode) at top of board. Solder and trim leads.
  - () <u>Step 7</u>. Install heat sink in Area H,J-1,2,3,4. Position the large, black heat sink (flat side to board) over the square foil area in the upper right corner. Orient the sink so that the triangle of holes is under one of the triangular cut-outs in the sink. Using two 6-32 screws, nuts, and lockwashers, attach the heat sink to the board. Insert screws from back (solder) side of board. (See Figure 2-2.)

() <u>Step 8</u>. Install IC49 (340T-5.0V or 7805UC) in Area J-1,2,3. Position IC49 on heat sink and observe how the leads must be bent to fit the mounting holes. Note that the center lead (3) must be bent downwards at a point approximately 0.2 inches further from the body than the other leads. Bend the leads so that no contact is made with the heat sink when IC49 is flat against the sink and its mounting hole is aligned with the hole in the sink. Fasten IC49 to sink using 6-32 screw, lockwasher and nut. Insert screw from back (solder) side of board. Solder and trim leads. (See Figure 2-2.)




Figure 2-2. Heat sink and IC49 installation.

- () <u>Step 9</u>. Install IC50 in Area A-9. (See detail drawing on component location diagram.) Install IC50 with flat facing left. Bend center lead back to fit into mounting hole. Push straight down until the IC is stopped by its leads. Solder and trim leads.
- ( ) <u>Step 10</u>. Install crystal Yl in Area D-1,2. (See detail drawing on component location diagram.)
  - ( ) Install Yl so that it lies flat against board as shown (case at top of board), solder leads and trim. Using a piece of excess crystal lead, ground the crystal case as indicated in the detail drawing. First solder on the back side of board. Then solder the lead to the crystal case. (See CAUTIONS on Page II-10.)

#### CAUTION 1

SOLDER QUICKLY SO THAT EXCESSIVE HEAT WILL NOT BE APPLIED TO CRYSTAL.

## CAUTION 2

THE CRYSTAL GROUND LEAD MUST NOT SHORT TO TOP TRACE ON BACK (SOLDER) SIDE OF BOARD. IF THIS SHORT DOES EXIST, THE COMPUTER FUSE WILL BLOW.

( ) <u>Step 11</u>. Check that crystal Yl ground is not shorted to top trace on back (solder) side of board. Use an ohmmeter to measure the resistance between the top trace on the back side of the board and the crystal case. You should measure some resistance. Zero resistance indicates a solder bridge. Correct the condition.

Proceed to Step 12 if you measure some top trace-to-crystal case resistance.

- ( ) <u>Step 12</u>. Check regulator operation. This check is made to prevent potential subsequent damage to the ICs from incorrect voltages.
  - ( ) Install VDM-1 in computer. (The use of a Processor Technology EXB Extender Board is recommended.)

### CAUTION

NEVER INSTALL OR REMOVE CIRCUIT BOARD WITH POWER ON. TO DO OTHERWISE CAN DAMAGE THE BOARD.

( ) Turn power on and make the following voltage measurements:

MEASUREMENT POINT	AREA	VOLTAGE
Pin 3 of IC50 Anode of Dl	A-8,9 A-10	12 vdc ± 5% -3 vdc ±10%
Pin 14 of ICl	A-2	5 vdc ± 5%

 ( ) If any voltages are incorrect, determine and correct the cause before proceeding. Especially check for solder shorts.

If voltages are correct, go on to Step 13.

( ) <u>Step 13</u>. Install jumper in Area D,E-9. Cover a piece of excess resistor lead with  $\frac{1}{4}$ " spaghetti, bend to fit holes, insert, solder and trim.

- ( ) <u>Step 14</u>. Install coaxial cable in Area A,B-1. (See Figure 2-3 for details on how to prepare cable.)
  - ( ) Strip away approximately 1¼" of the outer insulation to expose the shield. Unbraid shield, gather and twist into a single lead. Then strip away the inner conductor insulation, leaving about 1/4" at the shield end.

# CAUTION

WHEN PREPARING AND INSTALLING SHIELD, BE SURE BITS OF BRAID DO NOT FALL ON-TO BOARD. SUCH DEBRIS CAN CREATE HARD-TO-FIND SHORT CIRCUITS.




Figure 2-3. Coaxial cable preparation.

( ) Insert inner conductor in indicated mounting hole, solder and trim. Solder shield to ground plane and trim. Install tie wrap as shown.

## CAUTION

AFTER INSTALLATION, FINE BITS OF THE BRAID FROM THE SHIELD MAY WORK LOOSE AND FALL ONTO THE BOARD AND CREATE HARD-TO-FIND SHORT CIRCUITS. TO PRE-VENT THIS, COAT ALL EXPOSED BRAID WITH AN ADHESIVE AFTER SOLDERING AND BEFORE TIEING. USE AN ADHESIVE SUCH AS SILICONE, CONTACT CEMENT OR FINGERNAL POLISH. DO NOT USE WATER BASE ADHESIVES.

() Step 15. Install DIP Switch in Area B-1,2. Position it so Switch No. 1 is at left end of pad. As you will note, the DIP Switch pad is designed to accommodate a 7-position switch. If a 6-position (12 pin) switch is supplied, position it as far to the left as possible. (The two holes to the right will be unused in this case.) If a 7-position (14 pin) switch is supplied, remember that Switch No. 7 is not used.

# NOTE

The function of the DIP switches is defined in Section III of this manual.

II-11

( )  $\underline{\text{Step 16}}$  . Install the following ICs in the indicated locations. Pay careful attention to the proper orientation.

#### NOTE

Dots on the assembly drawing and PC board indicate the location of pin 1 of each IC.

IC NO.		NO.	AREA	TYPE
(	)	ICl	A-2,3	7406
(	)	IC2	A-3,4	74LS163
(	)	IC7	B-3	74LS20
(	)	IC8	B-4,5	93L16
(	)	IC9	B-6,7	74LS10
(	)	ICl4	C-4,5	74LS02
(	)	IC15	C-6	74LS00
(	)	IC16	C-7	74LS109
(	)	IC19	D-3,4	74LS04
(	)	IC20	D <b>-</b> 5	74LS163
(	)	IC21	D-6	74LS163
(	)	IC22	D <b>-7</b>	74LS163

- ( ) <u>Step 17</u>. Check timing chain operation. If you do not have an oscilloscope, proceed to Step 18.
  - ( ) Install VDM-1 in computer. (The use of a Processor Technology EXB Extender Board is recommended.)

#### CAUTION

NEVER INSTALL OR REMOVE CIRCUIT BOARD WITH POWER ON.

( ) Turn power on. Using an oscilloscope, check for the waveforms given in Figure 2-4 at the indicated observation points and in the order given. The waveforms shown in Figure 2-4 approximate actual waveforms. If any waveforms are incorrect, determine and correct the cause. Especially check for solder bridges and incorrectly installed ICs.

# NOTE

Irregularities up to 1 volt are acceptable on positive portions of waveforms. Negative portions, however, should be relatively flat.

If all waveforms are correct, proceed to Step 18.

# VDM-1 VIDEO DISPLAY MODULE

SECTION II

CHECK POINT	<u>AREA</u>	<u>WA</u>	VEFORM
( ) IC19, pin 3	D-3,4		ave. (This is not a ve. It in fact more sine wave.)
( ) ICl9, pin ll	D-3,4	300 nsec	· 375 nsec
( ) ICl9, pin 13	D-3,4	75 nsec	600 nsec
( ) IC22, pin ll	D-7	5 usec	5 usec
( ) IC21, pin 11	D-6	50 usec	12 usec
( ) IC2, pin ll	A-3,4	350 usec	520 usec
( ) IC8, pin ll	B-4,5	10 msec	6.7 msec
( ) IC16, pin 10	C-7	13.5 msec	3.3 msec

Figure 2-4. Timing Waveforms

#### VDM-1 VIDEO DISPLAY MODULE

SECTION II

( ) <u>Step 18</u>. Install the following ICs in the indicated locations. Observe the same general instructions given in Step 16.

IC NO.		NO.	AREA	TYPE
(	)	IC12 IC25*	C-2 E-3	74LS86 4049
ì	í	IC30*	F-3	4001

\*MOS devices. Refer to CAUTION on Page II-3.

- ( ) <u>Step 19</u>. Check synchronization circuits.
  - ( ) Set DIP Switch as follows:

Switch No. 1: ON All other switches: OFF

- ( ) Install VDM-1 in computer. Observe CAUTION given in Step 17. Then connect VDM-1 to video monitor.
- ( ) Set R33 (VERT) and R50 (HORIZ) on the VDM-1 to their midrange settings. Turn computer and monitor on.

#### NOTE

In making this check, the Horizontal Hold Control on monitor may always be readjusted to center display.

( ) The display raster will be pulled in. Using the monitor vertical hold, you should be able to obtain a slow roll (black horizontal bar moves slowly down the screen) and a stationary raster. Using the monitor horizontal hold, you should be able to adjust for an out of sync raster (numerous black lines cutting across the raster) and a stable raster. If you do not observe these conditions, try adjusting R33 and R50 on the VDM-1. If you are still unable to obtain the indicated conditions, determine and correct the cause before proceeding.

#### NOTE

For a stable presentation, a few monitors—especially modified TV sets—may require a higher sync amplitude than that supplied by the VDM-1. In such cases, increase sync amplitude by reducing value of R2 (Area A-1). DO NOT DECREASE R2 BELOW 225 OHMS.

( ) If the aforementioned vertical and horizontal conditions are realized, turn Switch No. 1 OFF and Switch No. 2 ON. The monitor screen should darken, and you should be able to obtain the previously described vertical and horizontal conditions. If operation is not as described after turning Switch No. 1 OFF and Switch No. 2 ON, determine and correct the cause.

If the synchronization circuits are operating correctly, proceed to Step 20.

( ) <u>Step 20</u>. Install the following ICs in the indicated locations. Observe the same general instructions given in Step 16.

IC :	<u>NO.</u>	<u>AREA</u>	$\underline{\mathtt{TYPE}}$	
( ) ( ) ( ) ( )	IC3 IC4* IC5 IC6 IC17	A-4,5 A-6,7 A-8 A-9 C-8	74166 MCM6575,6576 or 74Ls175 74Ls175 74Ls175	6574

\*MOS devices. Refer to CAUTION on Page II-3.

## CAUTION 1

TO INSURE THAT IC4 WILL NOT BE DAMAGED BY STATIC DISCHARGE, GROUND YOURSELF TO COMPUTER CHASSIS, REMOVE IC4 FROM PACKAGE AND INSTALL ON VDM-1 BOARD.

## CAUTION 2

IC4 IS A CERAMIC PACKAGE AND FRAGILE. USE AN EVENLY DISTRIBUTED, EASY PRESSURE WHEN LOADING IC4.

#### CAUTION 3

PIN 1 ON IC4 IS INDICATED BY A RAISED BUMP ON TOP OF THE IC. TAKE CARE TO LOAD IT CORRECTLY.

- ( ) Step 21. Check video circuits and character generator (IC4).
  - ( ) Using wire jumpers and tack soldering technique, make the following TEMPORARY connections:

ICl5 (Area C-6): Pin 2 to 7
ICl7 (Area C-8): Pin 5 to 8
Pin 4 of IC7 (Area B-3) to pin 1 of IC8 (Area B-4,5)

( ) Set up DIP Switch as follows:

Switches No. 2 and 5: ON All other switches: OFF

- ( ) Install VDM-1 in computer. Observe CAUTION in Step 17. Then connect VDM-1 to video monitor.
- ( ) Adjust R33 and R50, and monitor Horizontal Hold Control if required, to center pattern on screen. Check for 16 lines of 64 white dashes (actually ASCII underscore characters) on black background. (See Figure 2-4.)
- ( ) Set Switch No. 1 to ON and Switch No. 2 to OFF. Check for 16 lines of 64 black dashes (ASCII underscores) on white background. (See Figure 2-5.)
- ( ) Set Switch No. 3 to ON. Check for 16 lines of 64 black dashes (ASCII underscores) on white background surrounded by black frame. (See Figure 2-6 on Page II-18.)
- ( ) Set Switch No. 3 to OFF and Switch No. 4 to ON. Black frame in preceding presentation should disappear and entire display should blink.
- ( ) Set Switch No. 1 and No. 4 to OFF and Switch No. 2 and No. 3 to ON. Check for 16 lines of 64 white dashes (ASCII underscores) on black background surrounded by white frame. (See Figure 2-7 on Page II-18.)
- ( ) Set Switch No. 3 to OFF and Switch No. 4 to ON. White frame in preceding presentation should disappear and entire display should blink.
- ( ) If your VDM-1 fails to pass any of the preceding tests, DO NOT PROCEED BEYOND THIS STEP without determining and correcting the problem.
- ( ) If your VDM-1 passes all of the preceding tests, REMOVE TEMPORARY JUMPERS installed at beginning of this step and go on to Step 22.
- ( )  $\underline{\text{Step 22}}.$  Install remaining ICs in the indicated locations. Observe the same general instructions given in Step 16.

	IC NO.	AREA	TYPE
( ) ( ) ( ) ( )	IC10	B-7,8	74LS109
	IC11	B-9	74LS138
	IC13	C-3	74LS109
	IC18	C-9,10	74LS132
	IC23 & 24	D-8,9,10	74LS157




Figure 2-4. Video circuit check: SW2 & 5 ON, SW1,3,4 & 6 OFF.




Figure 2-5. Video circuit check: SW1 ON, SW2 OFF. II-17





Figure 2-6. Video circuit check: SWl & 3 ON, SW2 OFF.



	IC NO	<u>).</u>	AREA		TYPE
()()()()()()	IC26 IC28 IC29 IC31 IC33 IC35 IC36 IC37 IC38 IC40	& 27* & 32* & 34 & 39	E-4,5 E-6 E-9 F-4,5,6 F-8,9,10 G-3 G-4,5 G-5,6 G-8,9,10 H-1,2,3		4029 74LS157 8131 4042 74LS08 74LS00 74LS04 8836 or 8T380 8097 or 8T97 74LS10
( )			H,J-5,6,7,8,9		91L02 or 21L02
	*MOS	device.	Refer to CAUTION	on	Page II-3.

( ) <u>Step 23</u>. Set VDM-l address. The Software included with the VDM-l, as well as future releases, requires setting the VDM memory address to CCØØ (hex) and the I/O control port to C8 (hex). To connect the VDM for these "standard" address assignments, wire jumpers as shown in Figure 2-8.




Figure 2-8. VDM-1 address jumpers, "standard" address assignments.

Should you wish to set your VDM-1 for other than the "standard" address assignments, proceed as follows: (Refer to Figure 2-9.)

- ( ) 1. Write down port address in binary form (ADRØ-7). ADRØ and 1 must always be zero.
- ( ) 2. Write down six-bit memory page address in binary form (ADR1Ø-15) directly below port address. Place bit 15 below bit 7, bit 14 below bit 6 and so forth.
- ( ) 3. Connect address selection jumpers in Area E-8,9 according to the following rules:
  - a. If both bits in a column (bits 6 and 14, for example) are "1", no jumper is installed.

#### VDM-1 VIDEO DISPLAY MODULE

- b. If both bits in a column (bits 4 and 12, for example) are "Ø", install a jumper between the corresponding output of IC29 and ground (GND).
- c. If the port and memory page address bits in a column are "1" and " $\emptyset$ " respectively (bits 7 and 15, for example), install a jumper between the corresponding output of IC29 and the Y row.
- d. If the port and memory address bits in a column are "Ø" and "l" respectively (bits 5 and 13, for example), install a jumper between the corresponding output of IC29 and the X row.

Figure 2-9 illustrates the preceding procedure assuming a port address of C4 (hex) and a memory page address of 6400 (hex).




Figure 2-9. Procedure for setting VDM-1 for other than "standard" address assignments.

- ( ) Step 24. Install ready jumper (J2) in Area C-10.
  - ( ) If your Altair has been modified so that the ready driver on the display board is connected to Bus Pin 3, install a jumper between J2 and PRDY.
  - ( ) If this modification has not been made, jumper J2 to XRDY.

- ( ) <u>Step 25</u>. Install 9-inch length of 8-conductor ribbon cable on front (component) side of board between Jl in Area A-10 and Jl in Area J,H-10.
  - ( ) To insure correct terminal-to-terminal interconnection, make a fold midway between the cable ends to form an inverted V. Figure 2-10 clearly illustrates this technique.




Figure 2-10. 8-conductor ribbon cable installation.

- 2.7 FINAL TEST PROCEDURES
- 2.7.1 VDM-1 DIP Switch Settings
  - ( ) Set Switches 2, 3, 5 and 6 to ON.
  - ( ) Set Switches 1 and 4 to OFF.

#### NOTE

With above settings, the VDM-1 is configured for normal video display (white on black background), non-blinking cursor, and unblanked control characters.

# 2.7.2 VDM-1 Installation

( ) Install VDM-1 in computer and connect VDM-1 to video monitor. Turn monitor on. Hold STOP Switch on and turn computer on. (This keeps computer from coming on in run mode and insures a random display for scroll test.

#### CAUTION

NEVER INSTALL OR REMOVE VDM-1 WITH COMPUTER POWER ON.

#### NOTE

Each time the VDM-1 is placed into operation, a random (garbled) display may appear on the screen. This is normal.

#### 2.7.3 VDM-1 Status Initialization

 Enter following program into computer memory beginning at address zero.

HEX ADDRESS	OP CODE	LINE NO.	MNEMONIC	
0000	3E 00	0005	MVI A, ØØH	*LOAD ACCUMULATOR *OUTPUT TO VDM PORT *LOOP
0002	D3 C8	0010	OUT C8H	
0004	C3 00 00	0015	JMP Ø	

 ( ) Execute this program by turning on the RUN Switch and then flipping it quickly back to STOP. This program initializes the VDM-1 to display all sixteen lines.

#### 2.7.4 Scroll and Status Change Test

The purpose of this test is twofold: 1) it checks scrolling operation, and 2) it allows you to become familiar with the operation of the VDM-1 status control port.


- ( ) Change first two bytes of program in Paragraph 2.7.3 to DB and FF hexidecimal. Also set the eight Sense Switches on your Altair or IMSAI front panel to OFF (zero). The program, if run continuously, will now output the Sense Switch data to the VDM-1 status control port.
- ( ) With all eight Sense Switches OFF, a full 16 line by 64 character display (1024 characters) should appear on the screen. Note contents of first line in display. Call this line A.
- ( ) As shown in Figure 2-11, Sense Switches Ø through 3 define the first display line in memory. Set Sense Switch Ø to ON (one). First line (A) in preceding display should shift to bottom of screen and the others should move up one line. Try various combinations of Sense Switches Ø through 3 and note where first line (A) appears in display. Once you are familiar with how Sense Switches Ø through 3 affect the display, set them to OFF.
- ( ) As shown in Figure 2-11, Sense Switches 4 through 7 determine the first displayed screen position. Set these four switches to ON. Only the bottom line on the screen

#### VDM-1 VIDEO DISPLAY MODULE


should be displayed. Try various combinations of Sense Switches 4 through 7. As each switch is changed, the display should appear to move up and down the screen with a black area above it. The first line on display, regardless of its vertical position on the screen, should remain the same.

( ) After becoming familiar with how Sense Switches 4 through 7 affect the display, try different combinations of <u>all</u> the Sense Switches. Do this until you are familiar with the various ways in which "scrolling" can be performed.

#### VDM-1 Status Port Bit Functions



#### VDM-l Address Allocation



NOTE: Character addresses always correspond to actual screen display position. Depending on status port control word, the line address may or may not correspond to the screen position.

Figure 2-11. VDM-1 status port bit functions and address allocation.

## 2.7.5 Hardware-Software Function Test

This test checks all VDM-1 hardware-software functions.

( ) Enter following program into computer memory beginning at address zero.

HEX ADDRESS	OP CODE	LINE NO.	MNEMONIC	
0000	3E 00	0010	MVI A,Ø	*INIT. SCREEN TO SHOW ALL 1024 CHARACTERS
0002	D3 C8	0020	OUT ØC8H	
0004	21 00 CC	0030	LXI H,ØCCØØH	*INIT. SCREEN POINTER
0007	06 00	0040	MVI B,Ø	
0009	05	0050	LOOP DCR B	*COUNT DOWN
A000	70	0060	MOV M,B	*PUT (B) ON SCREEN
000B	23	0070	INX H	*INCREMENT SCREEN POINTER
000C	7C	0800	MOV A, H	
000D	FE DO	0090	CPI ØDØH	*COMPARE POINTER WITH END OF SCREEN
000F	C2 09 00	0100	JNZ LOOP	
0012	3E 20	0110	MVI A,2ØH	*PUT "SPACE" IN (A)
0014	32 00 CC	0120	STA ØCCØØH	*MOVE (A) TO SCREEN
0017	32 74 CC	0130	STA ØCC74H	*MOVE (A) TO SCREEN
001A	32 F2 CC	0140	STA ØCCF2H	*MOVE (A) TO SCREEN
001D	76	0150	HLT	*WE'RE DONE!

( ) Set all eight Sense Switches on your Altair or IMSAI to OFF (zero) and turn RUN Switch on. The display shown in Figure 2-12 should appear on the screen. Three character positions in this display are blanked to provide reference points. They are as follows:




Figure 2-12. VDM-1 hardware-software test pattern (6574 character generator).

- The first character in the first display line is blanked to identify the first line in the display.
- The VT control character (character position 53) in the second display line is blanked to permit a CR blanking test.
- The CR control character (character position 51) in the fourth display line is blanked to permit a VT blanking test.
- ( ) Set DIP Switches 1 to ON and 2 to OFF. You should have the same display as shown in Figure 2-12.
- ( ) Set DIP Switch 2 on VDM-1 to OFF and Switch 1 to ON in that order. A reversed video equivalent of the display shown in Figure 2-12 should appear on the screen. That is, the first two display lines will be white on black, the third and fourth lines will be black on white, etc.

#### NOTE

DIP Switches 1 and 2 should never be on at the same time.

- ( ) Return DIP Switch 1 to OFF and Switch 2 to ON <u>in that order</u>.
- ( ) Set DIP Switch 3 to OFF and Switch 4 to ON in that order. The entire display shown in Figure 2-12 should blink.

#### NOTE

DIP Switches 3 and 4 should never be on at the same time.

- ( ) Return DIP Switch 4 to OFF and Switch 3 to ON  $\underline{\text{in that}}$  order.
- ( ) Set DIP Switch 5 to OFF. The VDM-1 is now configured to to blank all control characters. Text blanking from CR to end of line and VT to end of screen is also enabled. The display shown in Figure 2-13 should appear on the screen.

As can be seen, the control characters (character positions 33 through 51) in the second display line are blanked out. Text blanking from, but not including, the CR control character (character position 51) to the end of line accounts for the remaining blanked portion of the line. VT blanking begins with the 54th character position in the fourth display line and blanks out the remainder of the screen.

( ) Return DIP Switch 5 to ON and set Switch 6 to OFF. The VDM-1 is now configured to display control characters. Text.blanking from CR to end of line and VT to end of screen is also enabled. The display shown in Figure 2-14 should appear on the screen.

As can be seen, the second line is blanked from, but not including, the CR control character to the end of the line. The CR control character as well as the other control characters preceding it are displayed. Again, VT blanking acts on the last ll character positions in the fourth line as well as on all the following lines. The VT control character and the control characters preceding it in the fourth line are displayed.

- ( ) Return DIP Switch 6 to ON.
- ( ) At this point, if desired, you can put the VDM-1 through its scrolling paces by using the Sense Switches.

#### 2.7.6 Character Generator Test

This test is provided for two purposes: 1) it allows you to check the character generator in the VDM-1 by displaying each character individually, and 2) it gives you an opportunity to become familiar with the ASCII code.

( ) Set DIP Switches on VDM-1 as follows:

Switch No. 1 and 4: OFF All other switches: ON

( ) Enter following program into computer memory beginning at address zero.

HEX ADDRESS	OP CODE	LINE NO.	MNEMONIC	
0000 0002	3E 00 D3 C8	0010 0020	MVI A,Ø OUT ØC8H	*CLEAR A *OUTPUT VDM PORT (STATUS)
0004	DB FF	0030	IN ØFFH	*INPUT SENSE SWITCHES
0006	47	0040	REDO MOV B, A	
0007	3E DO	0050	MVI A,ØDØH	
0009	21 00 CC	0060	LXI H,ØCCØØH	*INITIALIZE SCREEN POINTER
000C	70	0070	MOVE MOV M,B	
000D	23	0800	INX H	*INCREMENT SCREEN POINTER
000E	BC	0090	CMP H	*COMPARE POINTER
(Program	continued	on Pa	ge II-28.)	




Figure 2-13. Control character and text (VT-CR) blanking (6574 character generator).



Figure 2-14. Text (VT-CR) blanking (6574 character generator).

#### PROCESSOR TECHNOLOGY CORPORATION

#### VDM-1 VIDEO DISPLAY MODULE

SECTION II

HEX ADDRESS	OP CODE	LINE NO.	MNEMONIC	
000F 0012	C2 OC OO DB FF	0100 0110	JNZ MOVE INPUT IN ØFFH	*INPUT SENSE SWITCHES
0014	в8	0120	CMP B	*COMPARE TO B
0015	CA 12 00	0130	JZ INPUT	
0018	C3 06 00	0140	JMP REDO	*LOOP

( ) Turn RUN Switch on. The first seven Sense Switches (Ø through 6) on your Altair or IMSAI may now be used to address each character in the VDM-1 character generator, for their setting is the binary representation of the addressed ASCII character.

## NOTE

The position of the eighth Sense Switch (7) determines whether the cursor is on or off.

 ( ) Using Sense Switches Ø through 6, individually address each of the 128 ASCII characters. (Refer to Figures 3-1A, B and C in Section III for ASCII code.)

For example, setting Sense Switches  $\emptyset$  and 6 to "1" and Sense Switches 1 through 5 to "Q" will address the character "A" (ASCII code  $1\emptyset\emptyset\emptyset\emptyset\emptyset1$ ). A full screen (16 lines by 64 characters) of A's should appear on the screen.

Setting Sense Switches  $\emptyset$ , 2, 4 and 5 to "1" and Sense Switches 1, 3 and 6 to "Q" will cause a 5 (ASCII code  $\emptyset$ 11 $\emptyset$ 1 $\emptyset$ 1) to be displayed.

SECTION III

THEORY OF OPERATION

VDM-1 VIDEO DISPLAY MODULE



#### 3.1 THEORY OF OPERATION

The VDM-1 can be broken down into eight functional sections: timing, synchronization and blanking, memory, character generation, cursor, video, scroll and computer interface. For the following discussions, refer to the VDM-1 schematic diagram in Section IV.

#### 3.1.1 Timing

Two inverter gates (ICl9)--connected as a high-gain non-inverting amplifier--and crystal Yl form a crystal-controlled 13.5 MHz DOT CLOCK. This frequency defines the period of one dot in a character display matrix. DOT CLOCK is applied to a binary counter (IC20) which is preset to count seven to divide DOT CLOCK by nine. Two 1.5 MHz outputs are supplied by IC20: LOAD CLOCK and CHARACTER CLOCK. The former is a low-active signal of one DOT CLOCK duration; the latter is a square wave that is high and low for four and five DOT CLOCK periods respectively. Both the LOAD and CHARACTER CLOCK low-to-high transitions occur synchronously to the same DOT CLOCK transition.

CHARACTER CLOCK, which defines the period for one character, is counted down in IC22 and 21, both of which are 4-bit binary counters. IC22 counts from Ø to 15 and provides a carry output to enable IC21. IC21 is preset to count 3 and reset at count 9 by the output of NAND gate IC15. Thus IC21 cycles through six counts, with each count representing 16 CHARACTER CLOCK pulses.

Reset of IC21 defines the lefthand margin of the display, counts 4 through 7 define successive groups of 16 character positions, count 8 defines the righthand display margin, and count 9 defines the first CHARACTER CLOCK in the lefthand margin of the display.

The outputs of IC22 provide the four lower address bits of the character position on display. The two least significant outputs from IC21 supply the two high order address bits.  $\rm Q_{D}$  (pin 11) and  $\rm Q_{C}$  (pin 12) of IC21 are SCAN ADVANCE and HDISP (horizontal display) respectively. The former is used to generate horizontal synchronization signals, and the latter defines the start of a horizontal scan line.

On count 9 of IC21, the output of NAND gate IC15 also enables IC2, the scan divider. IC2 counts the horizontal scan lines that that make up a row of characters and supplies the line number to the character generator ROM, IC4. IC2 is preset to count 15 for the first scan line in the row. With this line count, the character generator provides a blank spacer line between the preceding and current character rows. IC2 then counts from  $\emptyset$  to 11 lines. At the end of the 11th count, a decoder comprised of IC14 and 7 supplies a load pulse to IC2 which resets it to count 15.

This load pulse, after inversion, becomes the OVERFLOW LINE signal. OVERFLOW LINE enables the character row divider, IC8. IC8 resets itself with its carry output through IC9, with the reset count being determined by the state of IC16, the vertical display (VDISP) flip-flop. If IC16 is cleared, IC8 is reset to count  $\emptyset$ ; if IC16 is set, IC8 is reset to count 12. Thus IC8 counts four or 16 character rows when IC16 is set or cleared respectively during load. The total of 20 character rows (260 scan lines) represents a full field on the display raster.

### 3.1.2 Synchronization and Blanking

Horizontal and vertical synchronization signals are generated by two one-shot multivibrators consisting of three two-input NOR gates in IC30 and two inverters in IC25. Horizontal sync is triggered by SCAN ADVANCE and vertical sync by VDISP. Both circuits generate fixed-length sync pulses with adjustable starting times. C27 and C25 determine the length of the horizontal and vertical sync pulses respectively. The starting times with respect to triggering, are variable with R50 (HORIZ) and R33 (VERT) to provide continuous adjustment of the display position on the raster. An exclusive OR-gate in IC12 combines the two sync pulses into a composite sync (COMP SYNC) signal. Note that the use of the exclusive OR inverts the horizontal sync pulses when the vertical sync pulse appears. Since vertical sync information is extracted in the monitor by an integrating, or averaging, process, this technique maintains horizontal synchronization during the vertical sync period.

Two types of blanking are available in the VDM-1: control character blanking and video blanking. The former blanks control characters and causes cursor information to be displayed in their place. Video blanking forces portions of the video display to a white or black level, depending on whether normal or reverse video is selected with SWl and SW2. (See Paragraph 3.2.)

Control character blanking, switch selectable with SW5 and SW6, is accomplished with one gate in ICl4 and one gate in ICl5. When a control character is present in the data latch (IC5 and 6), ICl4 is satisfied. Assuming the blanking option is selected, the output of ICl4 is gated with LOAD CLOCK in ICl5 to clear the video parallel-to-serial converter, IC3. IC3 then loads all zeros instead of the character.

Video blanking is initiated by the  $\overline{\text{PRE BLANK}}$ ,  $\overline{\text{POST BLANK}}$ , or  $\overline{\text{BLANK}}$  inputs to IC7, a four-input NAND gate. The fourth input, the video output of the cursor circuit, is blanked when any of the three blanking inputs is active.

The PRE BLANK input provides "window shade" blanking which is analogous to pulling a window shade down from the top of the display. PRE BLANK is generated in one half of ICl3. ICl3 is reset active during V SYNC and set inactive during START DISPLAY. The

latter is generated by the scrolling circuitry and defines the character row for which the window shade ends. START DISPLAY may begin with any character row from zero through 14.

POST BLANK blanks all character rows following the row in which a VT control character appears if the CR/VT option is selected by SW5 or SW6 (see Paragraph 3.2). POST BLANK is generated in one flip-flop in ICl6. This flip-flop is set inactive during V SYNC and reset active during OVERFLOW LINE if the VT flip-flop is set to indicate a VT control character.

The remaining video blanking function concerns the  $\overline{\text{BLANK}}$  output from one section of ICl7. This signal is a composite of HDISP, VDISP and the two control characters VT and CR. Since the blanking effects of these signals are character-position critical, timing is also critical. Thus, two D-type flip-flops in ICl7 are used to insure synchronization.

The first flip-flop is active (low) only when HDISP and VDISP are high at ICl5. Thus, the output of this flip-flop is active during the time a displayable character is latched into the data latch (IC5 and 6). The output of the first flip-flop is applied to one input of a three-input gate in IC9. IC9 is active (low) only when all of its inputs are high. A low input to IC9 will therefore over-ride any other high inputs.

Outputs from the VT and CR flip-flops (ICl0) are the other two inputs to IC9. VT and CR are active (low) from the first LOAD CLOCK during which either character is present in the data latch. This assumes the CR/VT option is enabled. Both the VT and CR flip-flops are set inactive during SCAN ENABLE. Thus, the blanking effect of VT and CR lasts from the character following VT or CR to the end of the character row.

The VT and CR blanking signals are generated by ICll, ICl0, ICl6 and their associated circuitry. In order to enable an output from ICll, the inputs to pins 6, 4 and 5 must be active. If pin 6 is grounded with SW5 and 6, the output of ICl4 is disabled to deselect the VT/CR option. Otherwise pin 6 will be active (high) when ICl4 decodes a control character in the output of the data latch (bits 5 and 6 are zero). Pin 4 is active (low) when IC9 decodes a control character (bit 3 zero and bit 4 high) when PRE BLANK is inactive (high). Pin 5 is active when DISPLAY is active (low). DISPLAY is low during all video display times. With ICl1 enabled, it supplies outputs when the three low-order bits from the data latch reflect the VT or CR ASCII code, 0001011 and 0001101 respectively.

The CR output of ICll (Pin 10) resets the CR flip-flop (ICl0) active at the end of the CR control character. VT flip-flop (ICl0) is likewise set active by the VT output of ICll (pin 12). Both sections in ICl0 are set inactive by LOAD CLOCK during SCAN ENABLE.

CR and VT blanking are consequently effective from the start of the character position following the control character to the end of the character row. When the VT flip-flop is set inactive at the end of the last scan line in the row, the POST BLANK flip-flop (ICl6) is also reset active since OVERFLOW LINE becomes active. Thus, VT initiated blanking continues to the end of the screen.

### 3.1.3 Screen Memory

Screen memory in the VDM-1 consists of eight 1 x 1024 bit RAM (random access memory) chips, IC41 through IC48. All chips are held enabled. Memory addressing is provided through a two-to-one multiplexer (IC23, 24 and 28) which selects one of two address sources: external address from the computer or internal character address from IC21, 22, 26 and 27. The last two ICs make up the scrolling counter. Normally the internal address is multiplexed to memory. When the computer requests access, the multiplexer switches to the external address lines, ADRØ through 9. The write enable (WE) input to IC41 through 48 are active only during external addressing when WRITE at pin 8 of IC18 is low.

#### 3.1.4 Character Generation

Two latches, IC5 and 6, latch data from the screen memory. The output from IC46 is inverted before being applied to pin 12 of IC5, and the complement (pin 11) of the  $Q_{\rm c}$  output is used in addressing the character generator ROM, IC4. This enables the data latch to present a SPACE code to the ROM when it is cleared. Bit 8 from the latch is used for the cursor and does not enter the ROM.

IC4 has seven character address inputs, four row select inputs and seven data outputs. It is programmed to generate seven bits (dots) of character information for the selected scan line of the character row. The complete pattern of IC4 is shown in Figure 3-lA, B and C.

The ROM output is converted from parallel to serial form in IC3, a shift register, and applied to one gate in IC12. This gate is the first component in the video circuitry.

#### 3.1.5 Cursor Circuit

A blink oscillator (two inverter sections in IC25), a latch (one section in IC17) and their associated components comprise the cursor circuit. The blink oscillator runs continuously at a rate set by R21 and C20. Its output has a nominal 0.5 sec period. If the blink option is selected with SW4 (see Paragraph 3.2), the blink signal is applied to one input of a gate in IC14. The other input to this gate is provided by the cursor latch, one section in IC17. If bit 7 out of the data latch is high, IC17 sets for the time the ROM is active on the character and remains set during the period when video data is shifted out of IC3. The output of IC17




Figure 3-1A. MCM6574 pattern.

is gated high through IC14 when BLINK is low. (BLINK) is held low when the blink option is not selected.) The output of IC14 is in turn gated with the video output of IC3 in IC12, an exclusive OR gate. IC12 thus inverts the video if the output of IC14 is high, and no inversion takes place if the output of IC14 is low.

### 3.1.6 Video Circuit

The video signal, including the cursor, is gated to SWl and 2 by IC7 in the absence of any blanking signals at the other three inputs to IC7. With SW2 closed, video and COMP SYNC are applied through two inverters in ICl to a resistive mixer, Rl through R3. This mixer has a 75-ohm output impedance. The two signals are mixed to meet EIA composite video signal requirements and coupled to the output by Cl. If only SWl is closed, another inverter in ICl inverts the video signal to produce a reverse (black on white) display.




Figure 3-1B. MCM6575 pattern.

## 3.1.7 Scroll Circuit

The scroll circuit is made up of IC26, 27, 31 and 32 and their associated circuitry. IC26 and 27 are up/down counters that are preset by the outputs of latches IC31 and 32. IC31 and 32 latch the character row information specified on DIØ through 7. IC26 is preset during VDISP, the time from the bottom of the displayed text to the top of the next vertical display period. IC26 is held at the preset number during this period, and counting is disabled by OVERFLOW LINE. When the character row divider (IC8) advances at the end of the first character row in the display, IC26 is enabled to count down. IC26 provides a low on its TC output whenever the counter is at count zero. This TC active output is inverted in IC19 to supply the START DISPLAY signal (active high). PRE BLANK blanks the display until START DISPLAY goes active. START DISPLAY goes inactive when IC26 counts below zero during OVERFLOW LINE at the end of the character row.

During the active time of START DISPLAY, IC27 is loaded with the contents of IC32. IC27 is enabled, when OVERFLOW LINE is low, to count up from the start of the end of the first displayed character row. IC27 continues to count with the end of each following character row.




Figure 3-1C. MCM6576 pattern.

Since IC27 reloads to its preset value at the line for which the window shade ends, the display may be scrolled up or down by incrementing or decrementing the row number. Incrementing or decrementing the number in IC32 varies the window shade duration. Doing the same thing to the number in IC31, in the absence of window shade blanking, causes the display to scroll.

## 3.1.8 Computer Interface

IC29 compares the address bits, ADR1Ø through ADR15 with two possible binary comparison numbers. These numbers are set with the X, Y and GND (ground) jumper arrangement (ADDRESS SELECT). One comparison number, which relates to the page number to which the screen memory responds, is generated when there is no input on SINP or SOUT. The other is generated when either of these inputs is present and represents the six high-order bits of the I/O port address to which the status port responds. Note that the circuit requires that the two low-order bits of the I/O port address always be zero.

During PSYNC, when  $\emptyset 2$  is low, IC29 compares its inputs and the two comparison numbers. An internal latch in IC29 retains the

state of the comparison when its enable input goes high. The output from IC29 drives several circuits.

- 1. It enables the XRDY driver, IC38.
- 2. It enables a section in IC37 (low) and IC40 (high).

If SINP and SOUT are low, the other input to IC37 satisfies the gate to generate MEM SELECT (memory select). Should either be high and the two low-order I/O address bits (ADR8 and 9) are low, IC40 generates  $\overline{\text{I/O}}$  SELECT.

An active  $\overline{\text{I/O}}$  SELECT enables another gate in IC37 and a gate in IC35 to respond to PWR and PDBIN respectively. PWR supplies LOAD STATUS to IC31 and 32. These two latches will thus retain the state of the DO bus as the scrolling parameters. PDBIN generates STATUS OUT to enable IC39 (pin 15) to place the status bit on DIØ.

MEM SELECT performs three functions: 1) it immediately switches the address multiplexer (IC23, 24 and 28) to supply external addressing to the screen memory, 2) it enables one section of IC13, and 3) it enables one section in IC17.

The input to, and Q output of, ICl3 are gated during the time preceding the next  $\emptyset 2$  high-to-low transition to IC38, the XRDY driver. Transmission through IC38 causes a wait state in the computer. This wait period allows the screen memory addresses to settle and allows adequate time for the memory to come ready for data input or output.

A MEM GO (memory go) signal from ICl3, which occurs with the second  $\emptyset 2$  in the instruction cycle, indicates enough time has elapsed since addressing for the screen memory to transfer data. During the wait period, PDBIN or MWRITE hold in their active state (high). Hence, Either WRITE is given to the screen memory or DATA OUT enables the DI bus drivers as appropriate.

The output of IC17 prevents any possible interference with the display when the screen memory address is changed. When the address is changed, the display is overriden, and spurious data at the memory outputs can interfere with the display. When IC17 is set, it causes the data latch to reset to a SPACE code. The SPACE code remains until the next character clock following removal of MEM SELECT. As a result, a short (but not critical) line segment in the display is lost.

LOAD STATUS from IC37 also triggers a one-shot timer consisting of one section in IC30, one in IC25, and Ql. The buffered output of this one-shot is STATUS. STATUS goes high when the one-shot is triggered and remains high for 0.25 to 0.5 second. The computer, when performing an output instruction from the VDM-l port,

#### PROCESSOR TECHNOLOGY CORPORATION

VDM-1 VIDEO DISPLAY MODULE

SECTION III

can thus test the timer status by looking for a high on  $\text{DI}\emptyset$ . This allows a slow scroll rate without requiring complex timing routines in the CPU.

STATUS is also connected to an unused 7406 inverter section in ICl. The output of this inverter can be jumpered to any of the vector interrupt (VI) pins. In future systems with vectored interrupt, this output will eliminate the need to continuously test the timer status.

#### 3.2 SWITCH SELECTABLE OPTIONS

The VDM-1 has several switch-selectable operating features. These are: normal and reverse video display, blinking and non-blinking cursor, text blanking, and control character blanking. These options are selected by SW1 through SW6 in the DIP Switch located in Area B-1,2 on the circuit board.

SWl and 2 control the video display, SW3 and 4 control cursor, and SW5 and 6 control the text and control character blanking features. The role that each switch serves in configuring the VDM-l circuitry for the various options can be readily determined by reviewing the schematic diagram in Section IV of this manual. Table 3-l defines the options that are available with SWl through 6. (Table 3-l will be found on Page III-10.)

## VDM-1 VIDEO DISPLAY MODULE

Table 3-1. DIP Switch States vs Options.


SWITCHES				OPTION	
No.	State	No.	State		
1	OFF	2	OFF	No display.	
1	OFF	2	ON	Normal video (white on black background).	
1	ON	2	OFF	Reverse video (black on white background).	
1	ON	2	ON	NOT ALLOWED.	
3	OFF	4	OFF	All cursors suppressed.	
3	OFF	4	ON	Blinking cursor.	
3	OM	4	OFF	Non-blinking cursor.	
3	OM	4	ON	NOT ALLOWED.	
5	OFF	6	OFF	All characters suppressed. Only cursor blocks are displayed. Text blanking from CR to end of line and VT to end of screen enabled.	
5	OFF	6	ON	Control characters blanked. Text blanking from CR to end of line and VT to end of screen enabled.	
5	ON	6	OFF	Control characters are displayable. Text blanking from CR to end of line and VT to end of screen enabled.	
5	ON	6	OM	Control characters are displayable. Text blanking from CR to end of line and VT to end of screen disabled.	


SECTION IV


# DRAWINGS


VDM-1 VIDEO DISPLAY MODULE











APPENDICES

VDM-1 VIDEO DISPLAY MODULE





STATEMENT OF WARRANTY



### STATEMENT of WARRANTY

PROCESSOR TECHNOLOGY CORPORATION, in recognition of its responsibility to provide quality components and adequate instruction for their proper assembly, warrants its products as follows:

All components sold by Processor Technology Corporation are purchased through normal factory distribution and any part which fails because of defects in workmanship or material will be replaced at no charge for a period of 6 months following the date of purchase. The defective part must be returned postpaid to Processor Technology Corporation within the warranty period.

Any malfunctioning module, purchased as a kit and returned to Processor Technology within the warranty period, which in the judgement of P.T. Corp. has been assembled with care and not subjected to electrical or mechanical abuse, will be restored to proper operating condition and returned, regardless of cause of malfunction, with a minimal charge to cover postage and handling.

Any modules purchased as a kit and returned to P.T. Corp. which in the judgement of P.T. Corp. are not covered by the above conditions will be repaired and returned at a cost commensurate with the work required. In no case will this charge exceed \$20.00 without prior notification and approval of the owner.

Any modules, purchased as assembled units are guaranteed to meet specifications in effect at the time of manufacture for a period of at least 6 months following purchase. These modules are additionally guaranteed against defects in materials or workmanship for the same 6 month period. All warranted factory assembled units returned to P.T. Corp. postpaid will be repaired and returned without charge.

This warranty is made in lieu of all other warranties expressed or implied and is limited in any case to the repair or replacement of the module involved.

## APPENDIX II

# 8080 OPERATING CODE



© Processor Technology Corr

=	- 1997 -
×	-
굽	-
ž	Section.
m	- Taxable
ဌ	44.00.00
8	

MOV E.B   BO ADD B   AS XRA C   OBDH   Heat	= 16 bit address = all Flags except CARRY affected; (exception: INX & DCX affect no Flags)
ACCUMULATOR*  ACCUMULATOR*  E.G. 81 ADD B B B B B B B B B B B B B B B B B B	11 11
ACCUMULATOR*  ACCUMULATOR*  E.G. 81 ADD B B B B B B B B B B B B B B B B B B	11 11
	11 11
	11 11
	11 11
	L .
E (SOR)  MOOV E E MOOV H E MOO	. •
	ates
<b>&gt;</b>	it evalu
88 88 88 88 88 88 88 88 88 88 88 88 88	i ion
88888888888888888888888888888888888888	<ul> <li>constant, or logical arithmetic expression that evaluates to a 16 bit data quantity.</li> <li>aniy CARRY affected</li> </ul>
	hmetic y.
MOVE	ical/arit quantit
100 100 100 100 100 100 100 100 100 100	6 = constant, or logical/arithr to a 16 bit data quantity. t = only CARRY affected
% IIII 0+ <b>5</b>	onstant a 16 l
RESTART CF RST C	6 + π = 1 Ω 1 P
96 98 98 98 98 98 98 98 98 98 98 98 98 98	016
	10
5 \$ 0000 \$ ××0 ××0	aluates
RETURN CO RETURN	that ev
	hmetic expression that evaluates ty. cted
CALL CONZ COZ COZ COZ COZ COZ COZ COZ COZ COZ CO	exbre
CALL CONZ CONZ CONZ CONZ CONZ CONZ CONZ CONZ	thmetic ity. ected
C C C C C C C C C C C C C C C C C C C	s quant
те в > мети по от так так так так так так так так так та	constant, or logical/arithmel to an 8 bit data quantity.
- 6 0 0 0 0 ± 2 222222	tar ag
MOVE 10 10 10 10 10 10 10 10 10 10 10 10 10	cons To ar

8 = constant, or logical/arithmetic expression that evaluates to an 8 bit data quantity.

STAX B
INAX C
C
CCC CCC C
CCC CCC C
CCC CCC C
CCC CCC C
C
CCC C
CCC C
C
CCC C
C
CCC C
C
CCC , or logical∕arithmetic expression that evaluates it data quantity. NOn-Printing

NO NULL

NO BELL

NO TAB

NO LF

FORM

OD CR

11 X-ON

11 X-ON

11 X-OF

14 ESC

7D ALT MUB O Adr = 16 bit address HEX-ASCII TABLE ESC ALT MODE RUB OUT PSW PSW D8 . 8 v v

HEX-ASCII TABLE

2465 Fourth Street Berkeley, Ca. 94710 (415) 549-0857

Processor Technology Corp.

APPENDIX II

**∀ X S < C ⊣ O B O D O Z Z C X C − I O T M O C O D** 

APPENDIX III

LOADING DIP DEVICES

<u>and</u>

SOLDERING TIPS



### LOADING DIP (DUAL IN-LINE PACKAGE) DEVICES

Most DIP devices have their leads spread so that they can not be dropped straight into the board. They must be "walked in" using the following procedure:

- (1) Orient the device properly. Pin 1 is indicated by a small embossed dot on the top surface of the device at one corner. Pins are numbered counterclockwise from pin 1.
- (2) Insert the pins on one side of the device into their holes on the printed circuit card. Do not press the pins all the way in, but stop when they are just starting to emerge from the opposite side of the card.
- (3) Exert a sideways pressure on the pins at the other side of the device by pressing against them where they are still wide below the bend. Bring this row of pins into alignment with its holes in the printed circuit card and insert them an equal distance, until they begin to emerge.
- (4) Press the device straight down until it seats on the points where the pins widen.
- (5) Turn the card over and select two pins at opposite corners of the device. Using a fingernail or a pair of long-nose pliers, push these pins outwards until they are bent at a 45 degree angle to the surface of the card. This will secure the device until it is soldered.

#### SOLDERING TIPS

- (1) Use a low-wattage iron 25 watts is good. Larger irons run the risk of burning the printed-circuit board. Don't try to use a soldering gun, they are too hot.
- (2) Use a small pointed tip and keep it clean. Keep a damp piece of sponge by the iron and wipe the tip on it after each use.
- (3) Use 60-40 rosin-core solder ONLY. DO NOT use acid-core solder or externally applied fluxes. Use the smallest diameter solder you can get.
  - NOTE: DO NOT press the top of the iron on the pad or trace. This will cause the trace to "lift" off of the board which will result in permanent damage.
- (4) In soldering, wipe the tip, apply a light coating of new solder to it, and apply the tip to both parts of the joint, that is, both the component lead and the printed-circuit pad. Apply the solder against the lead and pad being heated, but not directly to the tip of the iron. Thus, when the solder melts the rest of the joint will be hot enough for the solder to "take," (i.e., form a capillary film).
- (5) Apply solder for a second or two, then remove the solder and keep the iron tip on the joint. The rosin will bubble out. Allow about three or four bubbles, but don't keep the tip applied for more than ten seconds.
- (6) Solder should follow the contours of the original joint. A blob or lump may well be a solder bridge, where enough solder has been built upon one conductor to overflow and "take" on the adjacent conductor. Due to capillary action, these solder bridges look very neat, but they are a constant source of trouble when boards of a high trace density are being soldered. Inspect each integrated circuit and component after soldering for bridges.
- (7) To remove solder bridges, it is best to use a vacuum "solder puller" if one is available. If not, the bridge can be reheated with the iron and the excess solder "pulled" with the tip along the printed circuit traces until the lump of solder becomes thin enough to break the bridge. Braid-type solder remover, which causes the solder to "wick up" away from the joint when applied to melted solder, may also be used.


### APPENDIX IV

# INTEGRATED CIRCUIT PIN CONFIGURATIONS




### VDM-1 VIDEO DISPLAY MODULE

APPENDIX IV




AIV-1




AIV-2

# VDM-1 VIDEO DISPLAY MODULE


APPENDIX IV






VDM-1 VIDEO DISPLAY MODULE


APPENDIX IV



AIV-5




AIV-6



AIV-7

# VDM-1 VIDEO DISPLAY MODULE

### APPENDIX IV





VDM-1 TERMINAL SOFTWARE



_					
					, i
		•			
				-	
	en de la companya				

#### << VDM DRIVER SOFTWARE INSTRUCTIONS >>

The VDM DRIVER SOFTWARE allows the display of printable data onto a television monitor or a modified regular television. The rate at which the data is displayed is controlled from the keyboard used as the input to the computer. The rate may be set from completely stopped to over 2000 characters per second! The entire screen may be cleared from the keyboard and the cursor may be turned on or off as desired. The display format is 16 lines of 64 characters. If the line being displayed exceeds 64 characters the screen is scrolled up and continued on the next screen line. Control characters are not displayed.

The VDM DRIVER program is called by a user output routine or by BASIC depending upon which version is used. In the BASIC version, a sense switch is used to send the data to either the screen or to a printer.

If you wish to use the VDM with MITS BASIC, use the BASIC-VDM DRIVER program which automatically loads the VDM DRIVER SOFTWARE and links itself to BASIC'S output routines.

For use with other programs the machine language VDM DRIVER should be loaded into memory and called by a users program with the data to be displayed in register B.

### BASIC-VDM DRIVER

The BASIC version of the VDM DRIVER operates with the same commands as the machine language version. The display speed may be changed during an active screen, (data being presented). The display and program may also be stopped by typing a 'space bar', and then resumed by typing any key except another space. If a number is typed, the display is resumed at the new speed. Changing speed when the display is not active is not possible when running BASIC. The BASIC-VDM DRIVER is also RELOCATABLE and the STATUS BITS and I/O PORTS are AUTOMATICALLY SET to the values your BASIC is running with.

#### MACHINE LANGUAGE VDM DRIVER

The software requires 512 bytes of memory and may be located anywhere in memory except the first 512 bytes that are used for the relocating hex loader. A simple BINARY loader is used to bootstrap in an Intel format checksum loader that allows the VDM DRIVER software to be placed anywhere in memory. It is usually best to put it in the last 512 bytes of available memory. A users program should CALL to the first location of the VDM DRIVER program with the data in register B. The driver will save the calling programs stack and all of its registers. The data is displayed on the screen and screen operations are performed by the VDM DRIVER, then the calling program's stack and registers are restored and a RETurn is executed.

VDM-1 VIDEO DISPLAY MODULE

APPENDIX V

#### VDM DRIVER OPERATION

1.) INITIALIZING THE SCREEN AND CURSOR
The first time the VDM software is accessed the cursor position
must be set. Type a SHIFT K or LEFT BRACKET "[". The screen
is cleared and the cursor is set to the bottom left.

#### SCREEN CONTROL COMMANDS FOR BASIC

CONTROL Z: CLEAR SCREEN AND INITIALIZE CURSOR

CONTROL A: TURN CURSOR ON/OFF

SCREEN CONTROL COMMANDS FOR MACHINE LANGAUGE SOFTWARE

SHIFT K or LEFT BRACKET ([): CLEAR SCREEN & INITIALIZE CURSOR

SHIFT M or RIGHT BRACKET (]): TURN CURSOR OFF/ON

SHIFT L or BACKSLASH (\): SET SPEED {not in BASIC program}
This command will allow the display speed to be changed
when there is no active display movement. " NEW SPEED (1-9)? "
will appear on the screen. A number 1 thru 9 may then be typed
amd the display speed will be adjusted accordingly. Any other
character typed will cause no change in the speed.

- 1 = NO DELAY [ about 2000 CPS or 2000 60 chr lines per min ]
  9 = GREATEST DELAY [ about 1.5 characters per second ]
- SPEED CONTROL:

During active display, (driver program being accessed), the speed may be changed or the display stopped. Type a number 1-9 and the speed will change and remain set at that speed until changed again. If the SPACE BAR is typed during display action, the screen will freeze until any key other than the space bar is typed. If a number is typed, the display will resume at the new speed, otherwise the display will resume at the last set speed. The SPACE BAR may be used to 'SINGLE STEP' the display.

NOTE: IN PROGRAMS SUCH AS "BASIC" THAT ALTER THE DATA AVAILABLE FLAG, IT MAY BE NECESSARY TO HIT A SPEED CONTROL VALUE TWICE. THE SAME IS TRUE FOR "BREAK" OR CONTROL "C" IN "BASIC".

MACHINE LANGUAGE VDM DRIVER LOADING INSTRUCTIONS

1.) SET THE BINARY BOOTSTRAP LOADER LISTED HEREIN INTO MEMORY STARTING AT LOCATION ZERO (0).

2.) SET THE SENSE SWITCHES TO THE DESIRED MEMORY LOCATION WHERE THE DRIVER SOFTWARE IS TO RESIDE.

THE 8 SENSE SWITCHES ARE USED BY THE LOADER AS THE STARTING HIGH ORDER BYTE OF MEMORY ADDRESS TO LOAD THE SOFTWARE INTO THE CORRECT LOCATION AND TO ADJUST THE HIGH ORDER ADDRESSES REFERENCED BY THE VDM DRIVER PROGRAM INTERNALLY.

Example:
TO LOAD THE DRIVER STARTING AT 4E00 (HEX); {047000 octal}
THE SENSE SWITCHES SHOULD BE SET TO READ 4E (HEX).

A15-down A14-UP A13-down A12-down : A11-UP A10-UP A9-UP A8-down

THE DRIVER WILL THEN LOAD INTO LOCATIONS 4E00H TO 4FFFH.

47000Q TO 47400Q
!!! MAKE SURE YOU SET THE SENSE SWITCHES PRIOR TO LOADING !!!!!!
Note: The driver will not load into locations 0-1FF as the loading routine resides there during load time.

- 3.) READ IN THE VDM DRIVER PAPER TAPE STARTING ON THE BLANK LEADER AT THE BEGINNING OF THE TAPE.
  Note: There are two sections of the paper tape. The first is the hex loader that is bootstraped into locations 25H-138H. The second part starts at the blank area on the tape about 3 feet from the beginning, and is the VDM DRIVER software in hexidecimal checksum relocate format. The binary load routine first loads the hex loading routine and them jumps to that routine and reads in the hexidecimal format VDM DRIVER software. The jump may be noted by a change in the front panel lights. The 'input' light should be on during the reading of the tape by the load routine.
- 4.) WHEN THE PAPER TAPE HAS BEEN READ THE PROGRAM OUTPUTS "LOAD COMPLETE" TO THE LOAD DEVICE PORT AND ENTERS A HOLD LOOP. THE VDM DRIVER MAY THEN BE CALLED BY ANY PROGRAM. THE DATA IN REGISTER "B" WILL BE DISPLAYED ON THE SCREEN. THE CALLING POINT WILL BE THE FIRST LOCATION USED BY THE DRIVER.

THE SCREEN MUST BE INITIALIZED THE FIRST TIME IT IS ACCESSED. TYPE 'SHIFT K' TO CLEAR SCREEN AND INITIALIZE CURSOR.

### 5.) ERRORS DURING LOADING

A. IF THE SENSE SWITCES INDICATE O OR 1, THE PROGRAM WILL PRINT "SET SENSE SWITCHES" TO THE LOAD DEVICE PORT.
THE SWITCHES SHOUD BE SET TO THE DESIRED ADDRESS AND THE PAPER TAPE REPOSITIONED TO ITS SECOND BLANK AREA. EXAMINE LOCATION 25H {045Q} AND HIT "RUN", AND TURN ON THE TAPE READER.

VDM-1 VIDEO DISPLAY MODULE

APPENDIX V

- B. IF THE LOADER CANNOT VERIFY THAT THE DATA LOADED IS CORRECT, "MEMORY ERROR" WILL BE OUTPUT TO THE LOAD DEVICE PORT.
  CHECK TO SEE THAT THE SENSE SWITCHES ARE SET TO THE CORRECT ADDRESS AND THAT MEMORY IS UNPROTECTED.
- C. IF THE CHECKSUM VALUE EACH 26 BYTES IS NOT CORRECT, "CHECKSUM ERROR" WILL BE OUTPUT. TRY READING THE TAPE AGAIN FROM THE SECOND BLANK AREA. RESTART THE LOADER PROGRAM FROM LOCATION 25H. IF CHECKSUM ERRORS STILL OCCUR, EITHER THE PAPER TAPE IS BAD OR IS NOT BEING READ PROPERLY.
- 6.) PORT ADDRESS AND STATUS BITS

THE PAPER TAPE AND LISTING ARE SET UP WITH THE FOLLOWING:

STATUS PORT = 0
DATA PORT = 1
DATA AVAILABLE FLAG BIT = 40H { 1000 } ACTIVE HIGH
TRANSMITTER BUFFER EMPTY BIT = 80H { 2000 } ACTIVE HIGH

ALL REFERENCE TO THIS SET UP IS INDICATED ON THE LISTINGS BY AN ARROW " <-----<->
"IF CHANGES ARE NECESSARY FIRST CHANGE THE BINARY BOOT LOADER AND READ THE PAPER TAPE UNTIL THE BLANK AREA 3 FEET FROM THE BEGINNING OF THE TAPE. STOP THE COMPUTER AND MAKE THE CHANGES IN THE HEX LOADER USING THE LISTING AS A REFERENCE. THEN RESTART THE HEX LOADER AT LOCATION 25H AND READ THE REST OF THE PAPER TAPE. AFTER THE TAPE HAS BEEN READ IN, MAKE THE CHANGES TO THE VDM DRIVER AGAIN USING THE LISTING AS A GUIDE. REMEMBER THAT THE HIGH ORDER ADDRESS BYTES WILL BE DIFFERENT ACCORDING TO THE ADDRESS THE PROGRAM WAS SET TO. THE LOW ORDER ADDRESS BYTES WILL CORRESPOND HOWEVER. IF YOUR STATUS IS ACTIVE LOW, CHANGE THE BYTES INDICATED BY AN ARROW " <---[ J(N)Z ]---<<< " TO "JNZ" OR "JZ" AS NEEDED. IF YOUR STATUS IS ACTIVE LOW, THE INSTRUCTIONS WILL BE THE OPPOSITE OF THOSE IN THE LISTING.

BASIC-VDM DRIVER LOADING INSTRUCTIONS

1.) LOAD BASIC

#### !!! IMPORTANT !!!

2.) LEAVE AT LEAST 512 BYTES OF MEMORY FREE ABOVE YOUR RESPONSE TO THE QUESTION "MEMORY SIZE? " DURING THE INITIALIAZION OF BASIC. THERE MUST BE ROOM FOR THE DRIVER ABOVE BASIC! EXAMPLE: IF YOU HAVE 20K OF MEMORY THEN THE DECIMAL EQUIVALENT IS 20480. 20480-512 = 19968 WHICH IS THE MAXIMUM VALUE YOU SHOULD TYPE FOR "MEMORY SIZE".

#### VDM-1 VIDEO DISPLAY MODULE

IT IS A GOOD IDEA TO SET THE "TERMINAL WIDTH" TO 63 FOR USE WITH THE VDM.

- 3.) AFTER BASIC INITIALIZED AND PRINTS "OK", TYPE "NEW", TYPE "NULL O", AND LOAD IN THE BASIC-VDM DRIVER PROGRAM.
- 4.) PUT SENSE SWITCH A8 UP AND TYPE 'RUN'.
  THE PROGRAM WILL ASK FOR INFORMATION REGARDING DESTINATION LOCATION, VDM MEMORY ADDRESS, VDM PORT ASSIGNMENT, ETC..

"WAIT A MONENT...." !!! IMPORTANT !!!
WHEN THE PROGRAM TYPES "WAIT A MOMENT....", IT IS PEEKING THROUGH
ITSELF TO DETERMINE STATUS AND I/O VALUES, PATCH POINTS, AND
LOADING THE VDM DRIVER SOFTWARE INTO MEMORY. THIS MAY TAKE
30 TO 60 SECONDS. ALL THE FRONT PANEL LIGHTS GO ON AND THEY
LOOK VERY STILL; BUT DON'T START TO WORRY THAT THE PROGRAM
HAS CRASHED...UNTIL ABOUT 2 MINUTES.....THEN WORRY.

- 5.) SENSE SWITCH A8 WILL NOW CONTROL THE DESTINATION OF OUTPUT. WHEN THE SWITCH IS UP, DATA WILL GO TO THE DEVICE BASIC WAS SET UP FOR SUCH AS A TELETYPE. WITH THE SWITCH DOWN, THE DATA WILL BE DISPLAYED ON THE TV SCREEN. THE SWITCH MAY BE CHANGED AT ANY TIME, INCLUDING DURING OUTPUT.
- 6.) TYPE CONTROL Z THE FIRST TIME THE SCREEN IS ACCESSED IT MUST BE INITIALIZED.

.....you won't use so much paper now

#### VDM-1 VIDEO DISPLAY MODULE

APPENDIX V

```
0000
                            0001 *
0000
                            0002 *
0000
                             0003 *
0000
                             0004 *
                                            <<< VDM DRIVER BOOTSTRAP LOADER >>>
                            0005 *
0000
                                                            BINARY
                            0006 #
0000
                                       THIS PROGRAM IS USED TO BOOTSTAP IN THE VDM DRIVER SOFTWARE. THE FIRST PART OF THE VDM TAPE IS AN INTEL HEX CHECKSUM LOADER THAT IS USED TO RELOCATE THE VDM DRIVER CODE ACCORDING TO THE SETTING OF THE SENSE SWITCHES ON THE FRONT PANEL.
0000
0000
                            0008 *
0000
                            0009 *
0000
                            0010 *
0000
                            0011 *
0000
                            0012 *
                            0013 * 0014 *
0000
                                        PLEASE REFER TO LOADING INSTRUCTIONS
0000
                                        FOR FURTHER INFORMATION ON THE LOADING
                            0015 *
0000
                                        PROCEEDURE.
0000
                            0016 *
0000
                            0017 * LOAD THIS PROGRAM STARTING AT LOCATION ZERO (0)
0000
                            0018 *
0000
                            0019 *
0000 21 25 00
                            0020 BEGIN
                                           LXI
                                                   H, STACK SET MEMORY ADDRESS
0003 F9
0004 4C
                                                            SET STACK POINTER
CLEAR REG C
                            0021
                                            SPHL
                                                   Ċ,H
                            0022
                                            MOV
0005 CD 19 00
                                            CALL
                                                   IN
7FH
                                                            GET BINARY BYTE WAIT FOR START BYTE
                            0023
0008 FE 7F
                            0024
                                            CPT
000A C2 00 00
                            0025
                                            JNZ
                                                   BEGIN
000D
                            0026 *
OOOD OD
                            0027 CHRIN
                                            DCR
                                                            DECREMENT BYTE COUNT
000E CA 25 00
0011 CD 19 00
0014 77
                            0028
                                            JΖ
                                                   STACK
                                                            JUMP TO HEX LOADER IF DONE
                                            CALL
                            0029
                                                   ΙN
                                                            GET BYTE
                            0030
                                                            PUT IT IN MEMORY
NEXT MEMORY ADDRESS
GET ANOTHER BYTE
                                            MOV
                                                   M,A
0015 23
                                            TNX
                                                   H
0016 C3 OD OO
                            0032
                                                   CHRIN
                                            JMP
0019
                            0033 *
0019 DB 00
                            0034 IN
                                            ΙN
                                                   STAT
                                                            GET CHR <----<<<
001B E6 40
                            0035
                                            ANI
                                                   DAV
                                                            DATA AVAILABLE? <----<
001D CA 19 00
0020 DB 01
                            0036
                                            JΖ
                                                   ΙN
                                                            GET DATA <----<<<
                            0037
                                            ΙN
                                                   DATA
0022 C9
                            0038
                                            RET
0023
0023
                            0040
                                           D.S
                            0041 STACK
0025
                                           EQU
                                                            STACK ADDRESS
0025
                            0042 *
0025
                            0043 *
0025
                            0044 DATA
                                            EQU
                                                            DATA PORT <----<<<
0025
                            0045 STAT
                                           EQU
                                                   0
                                                            STATUS PORT <----<<<
0025
                            0046 DAV
                                                   40H
                                           EQU
                                                            DATA AVAILABLE <----<
0025
                            0047
0025
                            0048 *
BEGIN
          0000
                     0025
CHRIN
          000D
                     0032
          0001
DATA
                     0037
DAV
          0040
                     0035
0023 0029 0036
0020 0028
          0019
ΙN
STACK
          0025
STAT
          0000
                     0034
```

```
0025
                                 0001 #
 0025
                                 0002 *
                                 0003 *
0025
                                               << INTEL CHECKSUM HEX LOADER FOR VDM-DRIVER >>
0025
                                 0004 *
0025
                                 0005 *
0025
                                 0006 *
                                                   VERSION 2.0 APRIL 11, 1976
                                                                                            S. DOMPIER
                                0007 *
0025
                                           THIS IS A MODIFICATION OF AN INTEL HEX CHECKSUM LOADER TO ALLOW RE-LOCATABLE LOADING OF THE VDM-DRIVER SOFTWARE. THE HIGH ADDRESS IS RCVD FROM THE SENSE SWITCHES, ZERO OR ONE NOT ALLOWED.
                                0008
0025
                                0009 *
 0025
0025
                                0011 *
 0025
                                0012 *
0025
0025
                                0013 #
0014 FIRST
0025 31 38 01
0028 06 3A
002A CD 18 01
                                                          SP, STACK STACK ADDRESS B, ':' START OF RECORD
                                                 LXI
MVI
                                0015 START
                                                          INB
                                0016
                                                  CALL
                                                                    GET CHARACTER
002D 90
002E C2 28 00
                                                  SUB
                                                                    RECORD MARK?
NO-WAIT FOR RECORD MARK
CLEAR CHECKSUM
                                0017
                                0018
                                                          START
0031 57
                                0019
                                                  MOV
0032 CD CO 00
0035 CA 7D 00
0038 5F
                                                                    GET RECORD LENGTH
IF RECORD=0 THEN DONE
RECORD LENGTH IN REG E
                                0020
                                                  CALL
                                                          RÉAD
                                0021
                                                  .17.
                                                          DONE
                                                  MOV
                                0022
                                                          E.A
0039 CD E6 00
                                0023
                                                  CALL
                                                          OFFSET
                                                                      GET MSB FROM DATA
                                                                    GET MSB FROM DATA
GET LSB OF ADDRESS
LSB IN REG L
003C 61
                                0024
                                                          H,C
READ
                                                  MOV
003D CD CO 00
                                0025
                                                  CALL
0040 6F
                                0026
0041 CD CO 00
                                                  CALL
                                                          READ
                                                                    SKIP RECORD TYPE
                                0027
0044
                                0028 *
                                                                    GET CHARACTER
PUT CHR IN MEMORY
CHECK IF MEMORY IS OK
0044 CD E6 00
                                0029 GETCH
                                                 CALL
                                                          OFFSET
0047 71
0048 BE
                                0030
                                                 MOV
CMP
                                                          M,C
                                0031
0049 C2 71 00
                                0032
                                                  JNZ
                                                          MERR
                                                                    NO- MEMORY ERROR
004C 23
004D 1D
                                0033
                                                  INX
                                                                    NEXT ADDRESS
                                0034
                                                  DCR
                                                                    RECORD LENGTH -1
004E C2 44 00
                                                  JNZ
                                                                    GET MORE
GET CHECKSUM
                                0035
                                                          GETCH
0051 CD CO 00
                                0036
                                                          READ'
                                                  CALL
0054 CA 28 00
                                0037
                                                  JΖ
                                                          START
                                                                    OK- GET NEXT RECORD
0057
0057 21 83 00
                                0039 CERR
                                                          H, CHKER CHECKSUM ERROR
005A CD FE 00
005D 7E
                                0040 MSG
0041 MSG2
                                                 CALL
                                                          CRLF
                                                          A, M
005E FE 58
                                0042
                                                 CPI
0060 CA 6B 00
0063 47
0064 CD 0D 01
                                0043
                                                  JΖ
                                                          HOLD
                                                  MOV
                                                          B,A
OUTB
                                0045
                                                 CALL
                                                                    PRINT CHR
0067 23
0068 C3 5D 00
006B
                                0046
                                                  INX
                                                          MSG2
                                0047
                                                  JMP
                                0048 *
006B CD FE 00
                                0049 HOLD
                                                 CALL
                                                          CRLF
006E C3 6E 00
0071
0071 21 92 00
0074 C3 5A 00
0077 21 9F 00
007A C3 5A 00
                                0050 HOLD2
                                                 JMP
                                                          HOLD2
                                0051
                                0052 MERR
                                                 LXI
                                                          H, ERR MEMORY EPROR
                                0053
0054 WHAT
                                                 JMP
LXI
JMP
                                                          MŚG
                                                          H,SENSW SET SENSE SWITCHES MSG
                                0055
                                                          H, LCMP
007D 21 B2 00
                                0056 DONE
                                                 LXI
                                                                    LOAD COMPLETE
0080 C3 5A 00
0083
0083 43 48 45
                                0057
                                                 JMP
                                                          MŚG
                                0058 #
       43 48 45 43
                                0059 CHKER
                                                 ASC
                                                          "CHECKSUM ERRORX"
       4B 53 55 4D
20 45 52 52
4F 52 58
```

APPENDIX V

VDM-1 VIDEO DISPLAY MODULE

0092	52	59	4D 20 4F	45	0060	ERR	ASC	"MEMOR	Y ERRORX"
009F	53 53 45 49	45 20	4E 53 43	53 57	0061	SENSW	ASC	"SET S	ĖNSE SWITCHESX"
00B2	4C 20	4F 43 4C	41 4F 45	4D	0062	LCMP	ASC	"LOAD	COMPLETEX"
00C0		-			0063				
0000 0003 0004 0005 0006	07 07 07 07	D1	00		0064 0065 0066 0067 0068	READ	CALL RLC RLC RLC RLC	NIBBLE	GET BYTE MOV LSB 4 BITS TO MSB 4 BITS
00C7					0069		MOV	C,A	SAVE NIBBLE
00C8 00CB		DI	00		0070		CALL	NIBBLE	
0000					0071 0072		ORA MOV	C	ADD TWO NIBBLES TOGETHER FOR A BYTE CHARACTER IN REG C
OOCD					0073		ADD	C,A D	ADD CHECKSUM
OOCE					0074		MOV	D, A	CHECKSUM IN REG D
OOCF					0075	NO	MOV	A,C	
00D0	C9				0076	_	RET		
00D1 00D1	CD	10	٥.		0077			Tun	ana aus
00D4			01		0079	NIBBLE	SUI	INB 'O'	GET CHR
00D6		50			0080		RC	. 0 .	REMOVE ASCII BIAS DONE IF 0-2FH
00D7	C6	E9			0081		ADI	io'-'G'	
00D9					0082		RC		DONE IF 47H-OFFH
OODA					0083		ADI	6	
0 ODC 0 ODF			00		0084 0085		JP ADI	NIB2 7	ADD 10 IF A-F
00E1		01			0086		RC		DONE IF 3AH-4OH
00E2	C6	0A			0087	NIB2	ADI	10	DONE II SHIL-YOU
00E4					0088		ORA	A	SET ZERO FLAG
00E5	C9				0089	_	RET		
00E6 00E6	רח	CO	00		0090	OFFSET	CALL	READ	CET CUP
00E9			00		0091	OFFSEI	SUI	8	GET CHR CHECK IF 8 OR 9
OOEB	CA	F3	00		0093		JZ	YES	onder it o on y
OOEE					0094		CPI	1	
00F0		CF	00		0095		JNZ	NO	
00F3					0096	YES	MOV	C,A	PRIN CRUCE CUITAGUA
00F6					0097 0098		IN CPI	OFFH 2	READ SENSE SWITCHES MUST BE > 1
00F8			00		0099		JC	WHAT	NO- ERROR
OOFB	81	•			0100		ADD	C	ADD OFFSET
OOFC					0101		MOV	C,A	
OOFD (	9				0102		RET		
OOFE (	06	O D			0103 0104		MVI	B,ODH	CARRIAGE RETURN
0100			01		0105	OHER	CALL	OUTB	CARRIAGE RELURN
0103	06	O A	-		0106		MVI		LINE FEED
0105			01		0107		CALL	OÚTB	
0108 (			0.1		0108		MVI		FILL
010D	עי	עט	U I		0109 0110		CALL	OUTB	`
010D I	ЭВ	00			0111		IN	STAT	<<<<
							••		

### VDM-1 VIDEO DISPLAY MODULE

APPENDIX V

```
010F E6 80
0111 CA 0D 01
0114 78
0115 D3 01
0117 C9
0118
0118 DB 00
                                                              ANI
JZ
                                                                        TBE
                                                                                     <---<<
                                        0113
                                                                         OUTB
                                        0114
                                                             MOV
OUT
                                                                        A,B
DATA
                                                                                     <---<<
                                                              RET
                                        0117 *
0118 INB
                                                                                     CHECK STATUS PORT <---<<<
DATA AVAILABLE? <---<<<
NO- WAIT <--[ J(N)Z ]---<<<
GET CHR FROM DATA PORT <---<<
                                                             IN
Ani
                                                                        STAT
DAV
INB
011A E6 40
011C CA 18 01
011F DB 01
0121 E6 7F
                                        0119
                                                             JZ
IN
ANI
                                        0120
                                        0121
0122
                                                                        DATA
                                                                        7FH
0123 C9
0124
0124
                                        0123
                                       0123
0124 #
0125 #
0126 STAT
0127 DATA
0128 DAV
0129 TBE
0130 #
0131 *
0132 STACK
0133 #
0134 #
                                                                                    STATUS PORT <---<<
DATA PORT <---<<<
DATA AVAILABLE <---<<<
TRANSMITTER BUFFER EMPTY <---<<<
0124
0124
0124
                                                             EQU
                                                                        0
                                                             EQU
                                                                        40H
                                                              FOU
0124
                                                             EQU
                                                                        80H
0124
0124
                                                             DS
                                                                        20
                                                                                     STACK AREA
0138
                                                             EQU
0138
0138
CERR
              0083
00FE
CHKER
                               0039
CRLF
                              0040 0049
0115 0121
DATA
              0001
                                       0121
DAV
              0040
DONE
              007D
0092
                               0021
ERR
                               0052
              0025
0044
006B
FIRST
GETCH
                               0035
HOLD
                              0043
HOLD2
              006E
                               0050
INB
LCMP
              0118
                               0016 0078 0120
              00B2
                              0056
0032
              0071
005A
MERR
MSG
                               0053 0055 0057
MSG2
              005D
                              0047
NIB2
              00E2
                              0084
NIBBL
              00D1
                              0064 0070
                              0095
0023 0029
0045 0105 0107 0109 0113
0020 0025 0027 0036 0091
              00CF
00E6
NO
OFFSE
OUTB
              010D
READ
SENSW
             00C0
009F
                              0054
STACK
              0138
                              0014
START
              0028
                              0018 0037
STAT
TBE
                              0111 0118
0112
              0000
              0080
WHAT
                              0099
YES
              00F3
                              0093
```

```
0800
                               0001 *
 0800
                               0002 *
0800
                                0003 *
                                                      <<< VDM DISPLAY DRIVER >>>
0800
                                0004 *
 0800
                               0005 *
                                                 VERSION 3.0 APRIL 12,1976 S.DOMPIER
 0800
                                0006
0800
                                0007 *
                               0008 *
0800
0800
                               0009 *
                                                 INPUT ROUTINE
0800
                               0010 *
                               0010 *
0011 * THIS ROUTINE SAVES THE CALLING STACK,
0012 * PERFORMS SCREEN OPERATIONS AND RETURNS
0013 * TO THE CALLING PROGRAM AFTER RESTORING
0014 * THE SYSTEM STACK. IT MAY BE USED WITH
0015 * PTCO. "SOFTWARE PACKAGE #1" WITH
0016 * EXELLENT RESULTS. THE CHARACTER TO BE
0800
0800
0800
0800
0800
                               OO17 * DISPLAYED SHOULD BE IN REGISTER B. 0018 *
0800
0800
0800
                               0019 *
0800
                               3333 *
                                             VDM MEMORY ADDRESS = CCOOH
                               3333 *
3333 *
0800
                                             VDM PORT = C8
DATA PORT = 1
0800
0800
                               3333 *
                                             STATUS PORT = 0
0800
                                             DAV = 40H
0800
                               3333 *
                                             TBE = 80H
0800
0800
0800
                               0020 *
                                                  CALL HERE WITH CHARACTER IN REG B
0800
                               0021 *
0800
                               0022 *
0800 22 B7 09
0803 21 00 00
0806 39
0807 31 F0 09
080A E5
                               0023 VDM
0024
                                               SHLD HLSAV SAVE HL
                                                LXI
                                                        H,O
SP
                               0025
                                                                  GET SYSTEM STACK POINTER
                                                DAD
                                                        SP, STACK SET NEW STACK
H SAVE SYSTEM STACK POINTER
D SAVE ALL REGISTERS
                               0026
                                                PIISH
                               0027
                                                       н
080B D5
                               0028
                                                PUSH
                                                       D
080C C5
080D F5
                               0029
                                                PUSH
                                               PUSH
CALL
                               0030
                                                       PSW
080E CD 1A 08
                               0031
                                                        SCREEN DO SCREEN OPERATIONS
0811 F1
                               0032
                                                POP
                                                        PSW
                                                                 RESTORE REGISTERS
0812 C1
0813 D1
                               0033
                                                POP
                                               POP
                                                        D
0814 E1
                               0035
                                                POP
0815 F9
0816 2A B7 09
                               0036
                                                SPHL
                                                        RESTORE SYSTEM STACK
                                               LHLD
                               0037
                                                       HLSAV RESTORE HL
BACK TO CALLING PROGRAM
0819 C9
                               0038
                                               RET
081A
081A
                               0039 *
                               0040 *
081A
                               0041 *
                                                       A,B
7FH
081A 78
081B E6 7F
                               0042 SCREEN MOV
                                                                  GET CHR
                               0043
                                               ANI
CPI
                                                                 STRIP MSB
DON'T WANT DELETE
081D FE 7F
                               0044
                                                        7FH
081F C8
                               0045
0820 FE 5F
0822 CA 2D 09
                              0046
                                               CPI
                                                        5FH
                                                                  BACKSPACE? (shift 0)
                                                       BKSPA
                                               JΖ
0825 FE 5B
0827 CA CE 08
082A FE 5D
                               0048
                                               CPI
                                                                 CLEAR SCREEN? (shift K)
                              0049
                                               JΖ
                                                       CLR
                                               CPT
                                                                 CURSOR OFF/ON? (shift M)
082C CA 41 09
                               0051
                                               JΖ
                                                        CURTG
082F FE 5C
0831 CA 81 08
                               0052
                                               CPI
                                                                 SPEED CONTROL? (shift L)
                              0053
                                               JΖ
                                                        SETSP
0834 FE OD
                              0054
                                               CPT
                                                       ODH
                                                                 CARRIAGE RETURN?
```

```
0836 CA 15 09
0839 FE 20
                                   0055
                                                              CHOT2
                                   0056
                                                     CPI
                                                              20H
 083B D8
083C
083C
                                   0057
                                                     RC
                                                                        DON'T DISPLAY CONTROL CHRS
                                   0058 *
                                   0059
 083C
                                   0060
 083C
083C
                                   0061 *
                                                      OUTPUT TIMER
                                  0062 *
0063 TIMER
0064
 083C
                                                     PUSH
                                                                        SAVE CHARACTER
GET DELAY TIME
                                                              PSW
 083D 3A B6 09
0840 67
                                                     LDA
                                                              SPEED
                                                              H, A
L, 80H
STATUS
                                   0065
                                                     MOV
                                                                        SET COUNTER IN HL
 0840 67
0841 2E 80
0843 CD A7 09
0846 CA 6E 08
0849 CD AC 09
                                   0066
                                                     MVI
                                   0067
                                                     CALL
                                                                        ANYBODY WANT IN?
                                                              NEXTS NO- CONTINUE <-----[ J(N)Z ]---<<< INPUT YES- SEE WHO IT IS
                                  0068
                                                     JΖ
                                                     CALL
 084C CD 52 08
084F C3 6D 08
0852
0852
                                   0070
                                                     CALL
                                                              NUMCK
                                   0071
                                                     JMP
                                  0072 *
0073 *
0074 *
0852
0852
0852
0852 FE 3A
0854 D2 77 08
0857 FE 31
0859 DA 77 08
085C E6 OF
085E 4F
085F AF
0860 37
                                                      CHECK FOR TIME CONTROL VALUE
                                   0075 *
                                                             '9'+1
WAIT
                                  0076 NUMCK
                                                    CPI
                                                                        NO- CHECK IF ASCII NUMBER 1-9 TO BIG
                                  0077
                                                     JNC
                                  0078
                                                     CPI
                                                             WAIT
                                  0079
                                                     JC
                                                                        TO SMALL
                                                                        JUST RIGHT- REMOVE ASCII BIAS
SAVE DELAY NUMBER
                                  0080
                                                     ANI
                                  0081
                                                     MOV
                                                             C,A
                                  0082
                                                     XRA
                                                                        CLEAR ACCUMULATOR
                                  0083
                                                     STC
                                                                        INITIALIZE DELAY BIT IN CARRY DECREMENT DELAY NUMBER
0861 0D
0862 CA 69 08
0865 17
0866 C3 61 08
0869 32 B6 09
086C C9
                                  0084 LESS
                                                    DCR
                                                                        STOP ROTATING DELAY BIT
SHIFT DELAY BIT LEFT
NEXT ROUND
                                  0085
0086
                                                     JΖ
                                                             FOUND
                                                    RAL
                                                             LESS
                                  0087
                                                     JMP
                                                                        STORE DELAY TIME
                                  0088 FOUND
                                                    STA
                                                             SPEED
                                  0089
                                                     RET
086D
                                  0090 *
086D 2B
086E 7C
                                  0091 NEXT
                                                    DCX
                                                                        DELAY MINUS ONE
       7C
B7
                                  0092 NEXT2
0093
0094
                                                    MOV
                                                             A,H
                                                                        GET HIGH BYTE OF DELAY COUNT
086F
                                                             A
NEXT
                                                                        IS IT ZERO?
NO- DELAY SOME MORE
0870 C2 6D 08
0873 F1
0874 C3 00 09
                                                    JNZ
                                  0095
0096
                                                    POP
                                                                        GET CHR
                                                             CHOUT
                                                    JMP
                                                                       TO THE SCREEN!
0877
0877
0877 FE 20
                                  0097 *
                                  0098 *
                                 0099 WAIT
0100
                                                    CPI
                                                             20H
                                                                        SPACE BAR?
0879 C0
0878 CD A7 09
087D CA 7A 08
0880 C9
                                                    RNZ
                                                                       NO- CONTINUE
                                                             STATUS YES- WAIT FOR KEYBOARD INPUT
WAIT2 <-----[ J(N)Z ]---<<
                                  0101 WAIT2
                                                    CALL
                                 0102
0103
0104 *
                                                    JΖ
                                                    RET
0881
                                 0105 *
0881
                                 0106 *
                                                   SET DISPLAY SPEED
0881
                                 0107 #
0881 CD 15 09
0884 21 BA 08
                                 0108 SETSP
                                                   CALL
                                                             CHOT2
                                                             H,MSG
A,M
'X'
                                                   LXI
MOV
                                 0109
                                                                       SPEED MESSAGE
0887
                                 0110 SET1
0888 FE 58
                                                   CPI
JZ
PUSH
                                 0111
                                                                       MESSAGE TERMINATOR
088A CA 96 08
088D E5
                                 0112
                                                             SET2
                                 0113
                                                            Н
088E CD 00 09
0891 E1
0892 23
                                                   CALL
                                                             CHOUT MESSAGE TO SCREEN
                                 0115
                                                   POP
                                 0116
                                                   TNX
                                                            Н
```

APPENDIX V

```
VDM-1 VIDEO DISPLAY MODULE
0893 C3 87 08
0896 CD A7 09
0899 CA 96 08
089C CD AC 09
089F FE 3A
08A1 D2 B4 08
08A4 FE 31
08A6 DA B4 08
08A9 F5
                                                             SET1
STATUS
                                                     JMP
                                  0117
                                  0118 SET2
                                                     CALL
                                                                         GET NEW SPEED
                                                     JZ
CALL
CPI
                                  0119
                                                                        WAIT FOR IT <----[ J(N)Z ]---<<<
                                                              INPUT
'9'+1
                                  0120
0121
                                                                        GET NUMBER
                                                              OPPS
                                                                        TO BIG
                                  0123
                                                     CPI
JC
                                                              111
                                                              OPPS
                                                                        TO SMALL SAVE IT
                                  0125
                                                     PUSH
                                                              PSW
08AA CD 00 09
08AD CD 15 09
08B0 F1
                                  0126
                                                     CALL
                                                              CHOUT
                                                                        DISPLAY IT
                                                              CHOT2
                                  0127
                                                     CALL
                                  0128
                                                     POP
                                                              PSW
08B1 C3 52 08
08B4 21 CC 08
08B7 C3 87 08
08BA 20 4E 45
                                                     JMP
                                                              NUMCK
                                  0130 OPPS
0131
                                                    LXI
JMP
                                                              H,MSG+18 PRINT "?"
                                                             SÉT1
" NEW SPEED (1-9)? X"
                                  0132 MSG
                                                     ASC
        20
45
31
3F
            53 50
44 20
2D 39
                     45
28
29
            20 20
                                  0133 *
0134 *
08CE
08CE
                                  0135 *
0136 *
0137 CLR
08CE
                                                      CLEAR SCREEN & INITIALIZE CURSOR
08CE
08CE 21 00 CC
08D1 7C
08D2 C6 04
08D4 36 20
08D6 23
                                                             H, VDMBASE VDM MEMORY ADDRESS <---<<<
                                                     LXI
                                  0138
                                                     MOV
                                                             A , H
                                  0139
0140 CLR2
                                                     ADI
                                                                        VDM MEMORY TOP
                                                     MVT
                                                                        CLEAR SCREEN
                                  0141
                                                     INX
08D7 BC
                                  0142
08D7 BC
08D8 C2 D4 08
08DB AF
08DC 32 B4 09
08DF 32 B5 09
08E2 32 B2 09
08E5 2F
                                  0143
0144
                                                     JNZ
                                                             CLR2
                                                     XRA
                                  0145
                                                     STA
                                                             BOSL
                                                                        BEGINNING SCREEN LINE
                                  0146
                                                    STA
STA
                                                             BOTL
CCP
                                                                        BEGINNING TEXT LINE CURRENT CURSOR POINTER
                                  0148
                                                     CMA
08E6 32 B3 09
08E9 3E 0F
08EB 32 B1 09
                                  0149
0150
0151
                                                                        CURSOR FLAG
SET CURSOR AT SCREEN BOTTOM
CURRENT LINE NUMBER
                                                     STA
                                                              CURF
                                                             A,15
CLN
                                                     MVI
                                                    STA
08EE CD F2 08
                                  0152
                                                     CALL
                                                              VDMOT
                                                                        SET VDM
08F1 C9
                                  0153
0154
08F2
08F2
                                  0155 #
                                  0156 *
0157 *
0158 VDMOT
08F2
                                                      OUTPUT BOSL AND BOTL TO VDM
08F2
08F2
        3A B4 09
                                                    LDA
                                                             BOSL
                                                                        INITIALIZE VDM
08F5 07
08F6 07
08F7 07
                                  0159
                                                     RLC
                                  0160
0161
                                                     RLC
RLC
08F8 07
08F9 21 B5 09
08FC B6
                                  0162
                                                     RLC
                                  0163
                                                     LXI
                                                             H, BOTL
                                                     ORA
08FD D3 C8
08FF C9
                                  0165
                                                              VDMDEV VDM PORT ADDRESS <----<
                                                     OUT
                                  0166
0167 *
0168 *
                                                     RET
0900
0900
                                  0169 *
0900
0900
                                  0170 *
                                                      STORE CHARACTER IN VDM MEMORY
                                  0171 *
0900 4F
                                  0172 CHOUT
                                                    MOV
                                                                         SAVE CHR
0901 3A B2 09
0904 47
                                  0173
                                                    LDA
                                                              CĆP
                                                                        GET CURRENT CURSOR POINTER
                                  0174
                                                     MOV
                                                             B.A
```

0905		В1		0175	LDA	CLN	GET LINE NUMBER
0908			09	0176	CALL	CLNA	CONVERT TO ADDRESS
090B		В2	00	0177	MOA	M,C	PUT CHARACTER ON SCREEN
	3	BZ	09	0178	LDA	CCP	ADVANCE CURSOR
090F 0910		40		0179	INR	A	
0910			09	0180 0181	CPI JNZ	64	WRAP AROUND?
0912		B2		0182 CHO		CHOT1 CCP	
0918		DΖ	09	0183	MOV	B.A	
0919		В1	09	0184	LDA	CLN	
091C				0185	CALL	CCUR	CLEAR CURSOR
091F			09	0186	CALL	SCRL	SCROLL UP
0922	97			0187	SUB	A	SET CURSOR TO LEFT MARGIN
0923		B2	09	0188 сно	ri sta	CCP	
0926				0189	MOV	B,A	
0927		B1		0190	LDA	CLN	
092A		83	09	0191	JMP	SCUR	SET CURSOR ON/OFF
092D				0192 *			
092D 092D				0193 * 0194 *			
092D				0197	BACK	SPACE	AND ERASE LAST CHR
092D		מם	00	ر ر ، ت		CCD	OFF CURSOR ROTHER
0930		В2	09	0196 BKSF 0197	PA LDA MOV	CCP	GET CURSOR POINTER
0931		В1	nα	0198	LDA	B,A CLN	
0934				0199	CALL	CCUR	CLEAR CURSOR
0937	2B	٠.	0)	0200	DCX	H	CLEAN CONSON
0938		20		0201	MVI	й, т	CLEAR CHR
093A				0202	DCR	В,	obsiin oim
093B	3A	B1	09	0203	LDA	CLN	
093E	C3	83	09	0204	JMP	SCUR	SET CURSOR
0941				0205 *			
0941				0206 *			
0941				0207 *	CURS	OR DISP	LAY (OFF-ON)
0941				0208 *			
0941		В3	09	0209 CURT		CURF	GET CURSOR FLAG
0944 0945		ъ э	00	0210	CMA	01100	
0945		B3 B2		0211	STA	CURF	SWITCH IT
094B		DΖ	09	0212 0213	LDA Mov	CCP	GET CURSOR POINTER
094C		B1	ng	0214	LDA	B,A CLN	GET LINE NUMBER
094F				0215	JMP	SCUR	CURSOR ON/OFF
0952	- 3	- 5	٠,	0216 *	0.11	DOOM	CONDON ON/OFT
0952				0217 *			
0952				0218 *	SCRO	LL SCRE	EN UP
0952				0219 *			
0952	21	В5	09	0220 SCRL		H,BOTL	
0955				0221	PUSH	Н	
0956				0222	MOV	Α,Μ	
0957				0223	INR	M	
0958 0959		00	00	0224	SUB	M	
095C		70		0225 0226	LXI	B,0	
095F		40		0227	CALL LXI	CLNA	
0962		70	20	0228 SCRL		B,2040F M,B	CLEAR BOTTOM LINE
0963				0229 SCRE	INR	L L	OBGRE BOITOM LINE
0964				0230	DCR	Č	
0965	C2	62	09	0231	JNZ	SCRL2	
0968				0232	POP	Н	
0969				0233	MOV	A,M	
096A		OF		0234	ANI	OFH	
096C				0235	MOV	M , A	
096D	C3	F2	08	0236	JMP	VDMOT	

```
0970
0970
0970
                                 0237 *
                                0238 * 0239 *
                                                   CONVERT LINE NUMBER IN REG A AND CHR
0970
0970
                                0240 *
                                                   POSITION IN REG B TO ADDRESS IN HL
                                0241 #
0970
0970 6F
0971 3A B5 09
0974 85
0975 0F
0976 0F
0977 6F
0978 E6 03
0970 67
0970 7D
097E E6 C0
                                0242 CLNA
                                                 MOV
                                0243
                                                  LDA
                                                          BOTL
                                                                    LOAD THE OFFSET FOR LINE O
                                                  {\tt ADD}
                                                          L
                                                                    REG A LOW 4 BITS IS LINE NUMBER
                                0245
                                                  RRC
                                0246
                                                  RRC
                                0247
                                                  MOV
                                                 ANI
ADI
                                0248
                                0249
                                                          VDMPAGE <---<<
                                                          H,A
A,L
OCOH
                                0250
                                                  MOV
                                0251
0252
                                                  MOV
                                                  ANI
0980 80
0981 6F
0982 C9
                                0253
                                                  ADD
                                0254
                                                  MOV
                                                          L,A
                                                 RET
 0983
                                0256
0983
0983
                                0257 * 0258 *
                                                   SET CURSOR TO LINE IN REG A AND CHARACTER POSITION IN REG B
0983
                                0259
 0983
                                0260 *
0983 E6 OF
0985 32 B1 09
0988 CD 70 09
                                0261 SCUR
                                                 ANI
Sta
                                                          OFH
                                                          CLN
                                0262
                                0263
                                                 CALL
                                                          CLNA
098B 78
098C 32 B2 09
098F 3A B3 09
                                0264
                                                 MOV
Sta
                                                          A,B
                                0265
                                0266
                                                 LDA
                                                          CURF
 0992 B7
                                0267
                                                 ORA
0992 B7
0993 7E
0994 CA 9B 09
0997 F6 80
0999 77
099A C9
                                                          A,M
CCUR2
                                                 MOV
JZ
                                0268
                                0269
                                                 ORI
                                                          80H
                                0271
0272
                                                 MOV
RET
                                                          M,A
099B E6 7F
                                0273 CCUR2
                                                 ANI
                                                          7FH
                                0274
0275
0276 *
099D 77
099E C9
                                                 MOV
RET
                                                          M,A
099F
                                0277 *
0278 *
0279 *
099F
099F
                                                   CLEAR CURSOR FROM LINE IN REG A
                                                   AND POSITION IN REG B
099F
099F CD 70 09
                                0280 CCUR
                                                 CALL
                                                          CLNA
09A2 7E
09A3 E6 7F
09A5 77
09A6 C9
09A7
                                                         A,M
7FH
M,A
                                0281
                                                 MOV
                                0283
                                                 MOV
                                0284
                                0285 *
                                0286 *
09A7
                                0287 *
                                                SPEED CONTROL INPUT ROUTINE
09A7
09A7 DB 00
                                0288 *
                                0289 STATUS IN
                                                          STAT
                                                                    STATUS PORT <---<<
09A9 E6 40
                                0290
                                                 ANI
                                                                    DATA AVAILABLE? <---<<
                                                          DAV
09AB C9
09AC
                                0291
0292 *
                                                 RET
09AC DB 01
                                0293 INPUT
                                                 IN
                                                                    DATA PORT <---<<
                                                          DATA
                                0294
09AE E6 7F
                                                 ANI
                                                          7FH
                                                                    STRIP MSB
09B0 C9
                                                 RET
09B1
                                0296 *
09B1
                                0297 *
                                0298 *
09B1
                                                  RAM STORAGE
```

### VDM-1 VIDEO DISPLAY MODULE

APPENDIX V

```
09B1
                                0299 *
 09B1 00
                                0300 CLN
                                                                   CUREENT LINE NUMBER
CUREENT CURSOR POSITION
CURSOR DISPLAY FLAG
                                                 DB
 09B2 00
                                0301 CCP
                                                 DB
                                                         0
 09B3 01
09B4 00
                                0302 CURF
                                                 DB
                                                                   BEGINNING OF SCREEN LINE
BEGINNING OF TEXT LINE
                                0303 BOSL
0304 BOTL
                                                 DB
                                                         0
 09B5 00
                                                 DB
                                                         0
 09B6 06
09B7
                                0305 SPEED
                                                 DΒ
                                                         6
                                                                   DELAY BYTE
                                0306 HLSAV
                                                 DS
                                                         2
 09B9
                                0307
 09B9
09B9
                                0308 *
0309 SP
0310 PSW
                                                 EOU
                                                         6
 09B9
                                                 EQU
                                                         OC8H VDM OUTPUT PORT <---<<<
OCCOOH VDM MEMORY ADDRESS <---<<<
 09B9
                                0311 VDMDEV EQU
 09B9
                                0312 VDMBASE EQU
                               0313 VDMPAGE EQU
0314 *
 09B9
                                                         VDMBASE/256 <---<<<
 09B9
                               0315 *
0316 STAT
0317 DATA
0318 TBE
 09B9
09B9
                                                EQU
                                                         0
                                                                   STATUS PORT <---<<
 09B9
                                                EOU
                                                                  DATA PORT <---<<<
TRANSMITTER BUFFER EMPTY <---<<
 09B9
                                                 EQU
                                                         80H
 09B9
                               0319 DAV
0320 *
                                                 EQU
                                                         40H
                                                                   DATA AVAILABLE <---<<
 09B9
 09B9
                                0321 *
0989
                                0322 STACK EQU
                                                        09FOH STACK AREA
 09B9
                               0323 *
0324 *
09B9
                        0047
0145 0158
0146 0163 0220 0243
0147 0173 0178 0182 0188 0196 0212 0265
0185 0199
BKSPA
            092D
BOSL
            09B4
BOTL
            09B5
CCP
            09B2
CCUR
            099F
CCUR2
            099B
                        0269
CHOT1
           0923
0915
                        0181
CHOT2
                        0055 0108 0127
0096 0114 0126
0151 0175 0184 0190 0198 0203 0214 0262
CHOUT
            0900
CLN
CLNA
           09B1
                        0176 0226 0263 0280
           08CE
CLR
                        0049
CLR2
           08D4
                        0143
CURF
                        0149 0209 0211 0266
0051
           09B3
CURTG
           0941
DATA
           0001
                        0293
DAV
           0040
                        0290
FOUND
           0869
                        0085
0023 0037
HLSAV
           09B7
INPUT
           09AC
                        0069 0120
                        0087
0109 0130
0071 0094
LESS
           0861
MSG
           08BA
NEXT
           086D
NEXT2
           086E
                        0068
NUMCK
           0852
                        0070 0129
0122 0124
OPPS
           08B4
           0006
081A
0952
PSW
SCREE
                        0030 0032 0063 0095 0125 0128
                        0031
0186
ŠCRL
SCRL2
           0962
                        0231
                       0191 0204 0215
0117 0131
0112 0119
           0983
0887
SCUR
SET1
SET2
           0896
                       0053
0025 0026
SETSP
           0881
           0006
```

# VDM-1 VIDEO DISPLAY MODULE

APPENDIX V

SPEED STACK STAT STATU TBE TIMER VDM VDMBA VDMBA VDMOT VDMOT	09B6 09F0 0000 09A7 0080 083C 0800 CC00 00C8 08F2	0064 0026 0289 0067 0137 0165 0152 0249	0101	0118
VDMOT		0152	0236	
			0070	
WAIT	0877	0077	0079	
WAIT2	087A	0102		

```
0000 REM
0002 REM
            <<< BASIC TO VDM-1 LINK PROGRAM >>>
0004 REM
0006 REM
                   PROCESSOR TECHNOLOGY CORP.
0008 REM
                   6200 HOLLIS STREET
0010 REM
                  EMERYVILLE, CALIFORNIA
0012 PRINT
0014 A$="(HEX) IS YOUR LAST ADDRESS, INPUT:"
0016 B$="GIVE ME YOUR VDM":C$="ADDRESS IN DECIMAL"
OO18 PRINT" <<< VDM TO BASIC LOADING AND LINKING PROGRAM >>>"
OO20 PRINT" WRITTEN IN BASIC LANGUAGE BY GORDON FRENCH": PRINT
0022 PRINT"REMEMBER, IF YOU DID NOT LEAVE THE LAST 512 BYTES"
0024 PRINT"OF YOUR LAST 4K OF MEMORY FREE WHEN RESPONDING"
0026 PRINT"TO '' MEMORY SIZE ? '' WHEN THIS BASIC WAS"
0028 PRINT"LOADED, YOU MUST RELOAD BASIC WITH THE CORRECTED" 0030 PRINT"INFORMATION FOR ''MEMORY SIZE''. ":PRINT:PRINT
0032 PRINT"INPUT DECIMAL NUMBER OF YOUR LAST 4K BOUNDRY"
0034 PRINT"(EXAMPLE: IF 4FFF "A$" 4(RETURN)"
0036 PRINTTAB(10)"IF 5FFF "A$" 5(RETURN)
0037 PRINTTAB(10) "IF AFFF "A$"10(RETURN)
                                                     ETC."
0038 INPUT L:IF L<=7 THEN S=0:GOTO 46
0040 PRINT"IS THIS 12K EXTENDED BASIC? (Y/N)":INPUT D$ 0042 IF D$="Y" THEN S=65536:GOTO 46
0043 IF D$<>"N"THEN 40
0044 GOTO 84
0046 IF L>15 OR L=0 THEN 32
0048 L=(L*4096)+3584:P=L/256:L=L-S
0050 PRINT"IS YOUR VDM MEMORY ADDRESS CC00(HEX)";
0052 PRINT" WITH PORT=C8? (Y/N)"
0054 INPUT D$:IF D$="Y"GOTO 64
0055 IF D$<>"N" THEN 50
0056 PRINTB$" MEMORY STARTING "C$:INPUT V2
0058 V1=INT(V2/256):V2=((V2/256)-INT(V2/256))*256
0060 PRINTB$" PORT "C$:INPUT V3:IF V3>255 GOTO 60
0062 GOTO 68
0064 V1=204:V2=0:V3=200:V4=192
0068 PRINT"A MOMENT PLEASE..."
0070 S=0
0072 FOR K=0 TO 4096
0074 A=PEEK(K)
0076 B=PEEK(K+1)
0078 IF A = 219 AND B = 0 GOTO 92
0080 IF A = 219 AND B = 1 THEN I=K:GOTO 106
0082 NEXT K
0084 PRINT"IT IS NOT POSSIBLE TO LINK VDM-1";
0086 PRINT" TO THIS BASIC BY MEANS"
0088 PRINT"OF THIS PROGRAM. SORRY!"
0090 GOTO 146
0092 IF S>0 THEN GOTO 100
0094 C=PEEK(K+2):D=PEEK(K+3):E=PEEK(K+4):F=K+4
0096 IF C<>230 THEN GOTO 82
0098 S=S+1:G=K:GOTO 82
```

```
0100 H=PEEK(K+3):J=0
   0102 F=F-256:J=J+1:IF F>256 GOTO 102
   0104 GOTO 82
   0106 FOR Y=L TO L+409
   0108 READ Z
  0110 IF Z<300 GOTO 138
0112 IF Z=300 THEN Z=V3: GOTO 138
  0114 IF Z=400 THEN Z=V2: GOTO 138
  0116 IF Z=500 THEN Z=V1: GOTO 138
  0118 IF Z=1001 THEN Z=P+1: GOTO 138
  0120 IF Z=1000 THEN Z=P: GOTO 138
0122 IF Z=2000 THEN Z=D: GOTO 138
  0124 IF Z=3000 THEN Z=E: GOTO 138
  0126 IF Z=4000 THEN Z=F: GOTO 138
0128 IF Z=5000 THEN Z=J: GOTO 138
  0130 IF Z=6000 THEN Z=H: GOTO 138
  0132 PRINT"THIS PROGRAM LOAD IS BAD.":
  0134 PRINT" PLEASE RELOAD THIS PROGRAM."
  0136 GOTO 146
0138 POKE Y,Z:NEXT Y
 0140 POKE G,195:POKE G+1,0:POKE G+2,P
0142 POKE I,205:POKE I+1,110:POKE I+2,P+1:POKE I+3,0
0144 PRINT"VDM-1 IS NOW LINKED TO BASIC":PRINT
  0145 PRINT"DO NOT ATTEMPT TO RE-RUN THIS PROGRAM !":PRINT
  0146 RESTORE
  0148 NULL 0
  0150 END
 0152 DATA219,255,31,210,13,1000,219,0,230,2000
 0154 DATA195, 4000, 5000, 241, 230, 127, 254, 32, 210, 43
0156 DATA1000, 254, 7, 194, 30, 1000, 245, 195, 6, 1000
0158 DATA254, 13, 202, 46, 1000, 254, 1, 202, 46, 1000
0160 DATA254, 26, 192, 254, 127, 200, 245, 229, 213, 197
0160 DATA254,26,192,254,127,200,245,229,213,197
0162 DATA205,58,1000,193,209,225,241,201,245,58
0164 DATA146,1001,103,46,128,205,105,1001,3000,104
0166 DATA1000,205,110,1001,50,140,1001,254,58,210
0168 DATA112,1000,254,49,218,112,1000,230,15,79
0170 DATA175,55,13,202,100,1000,23,195,92,1000
0172 DATA50,146,1001,43,124,183,194,103,1000,195
0174 DATA181,1000,254,32,194,103,1000,205,105,1001
0176 DATA3000,117,1000,195,103,1000,33,400,500,124
0178 DATA198,4,54,32,35,188,194,132,1000,175
0180 DATA50,144,1001,50,145,1001,50,142,1001,47
0182 DATA50,143,1001,62,15,50,141,1001,205,167
0184 DATA1000,62,13,245,195,181,1000,58,144,1001
0186 DATA7,7,7,7,33,145,1001,182,211,300
0188 DATA201,58,142,1001,71,241,254,13,202,223
0190 DATA1000,254,95,202,243,1000,254,1,202,3
 0190 DATA1000,254,95,202,243,1000,254,1,202,3
0192 DATA1001,254,26,202,126,1000,79,58,141,1001
0194 DATA205,50,1001,113,58,142,1001,60,254,64
0196 DATA194,233,1000,58,141,1001,205,97,1001,205
0198 DATA20,1001,151,50,142,1001,71,58,141,1001
0200 DATA195,69,1001,58,141,1001,205,97,1001,43
```

## PROCESSOR TECHNOLOGY CORPORATION

### VDM-1 VIDEO DISPLAY MODULE

APPENDIX V

0202 DATA54,32,5,58,141,1001,195,69,1001,58
0204 DATA143,1001,47,50,143,1001,58,142,1001,71
0206 DATA58,141,1001,195,69,1001,33,145,1001,229
0208 DATA126,52,150,1,0,0,205,50,1001,1
0210 DATA64,32,112,44,13,194,36,1001,225,126
0212 DATA230,15,119,195,167,1000,111,58,145,1001
0214 DATA133,15,15,111,230,3,198,500,103,125
0216 DATA230,192,128,111,201,230,15,50,141,1001
0218 DATA230,50,1001,120,50,142,1001,58,143,1001
0220 DATA183,126,202,93,1001,246,128,119,201,230
0222 DATA127,119,201,205,50,1001,126,230,127,119
0224 DATA201,219,0,230,6000,201,58,140,1001,254
0226 DATA3,194,125,1001,245,175,50,140,1001,241
0228 DATA201,219,1,230,127,254,1,202,46,1000
0230 DATA254,26,202,46,1000,201,0,0,0,1

APPENDIX VI

TELEVISION INTERFACE



# Television Interface

Anyone with a bunch of memory circuits, control logic and a wire wrap gun can whip up a digital video generator with TTL output levels. The problem as I see it is to get that digital video signal into a form that the TV set can digest. The care and feeding of digital inputs to the TV set is the subject of Don Lancaster's contribution to BYTE 2 — an excerpt from his forthcoming book, TV Typewriter Cookbook, to be published by Howard W. Sams, Indianapolis, Indiana.

... CARL

We can get between a TV typewriter and a television style display system either by an rf modulator or a direct video method

In the rf modulator method, we build a miniature, low power, direct wired TV transmitter that clips onto the antenna terminals of the TV set. This has the big advantage of letting you use any old TV set and ending up with an essentially free display that can be used just about anywhere. No set modifications are needed, and you have the additional advantage of automatic safety isolation and freedom from hot chassis shock problems.

There are two major restrictions to the rf modulator method. The first of these is that transmitters of this type must meet

certain exactly spelled out FCC regulations and that system type approval is required. The second limitation is one of bandwidth. The best you can possibly hope for is 3.5 MHz for black and white and only 3 MHz for color, and many economy sets will provide far less. Thus, long character line lengths, sharp characters, and premium (lots of dots) character generators simply aren't compatible with clip-on rf entry.

In the direct video method, we enter the TV set immediately following its video detector but before sync is picked off. A few premium TV sets and all monitors already have a video input directly available, but these are still expensive and rare. Thus, you usually have to modify your TV set, either

adding a video input and a selector switch or else dedicating the set to exclusive TV typewriter use. Direct video eliminates the bandwidth restrictions provided by the tuner, i-f strip, and video detector filter. Response can be further extended by removing or shorting the 4.5 MHz sound trap and by other modifications to provide us with longer line lengths and premium characters. No FCC approval is needed, and several sets or monitors are easily driven at once without complicated distribution problems.

There are two limitations to the direct video technique. One is that the set has to be modified to provide direct video entry. A second, and far more severe, restriction, is that many television sets are "hot chassis" or ac-dc sets with one side of their chassis connected to the power line. These sets introduce a severe shock hazard and cannot be used as TV typewriter video entry displays unless some isolation technique is used with them. If the TV set has a power transformer, there is usually no hot chassis problem. Transistor television sets and IC sets using no vacuum tubes tend to have power transformers, as do older premium tube type sets. All others (around half the sets around today) do not.


## Direct Video Methods

With either interface approach, we usually start by getting the dot matrix data, blanking, cursor, and sync signals together into one composite video signal whose

Don Lancaster Box 1112 Parker AZ 85344

by





form is useful to monitors and TV sets. A good set of standards is shown in Fig. 1. The signal is dc coupled and always positive going. Sync tips are grounded and blacker than black. The normal open circuit black level is positive by one-half a volt, and the white level is two volts positive. In most TV camera systems, intermediate levels between the half volt black level and the two volt white level will be some shade of gray, proportionately brighter with increasing positive voltage. With most TV typewriter systems, only the three states of zero volts (sync), half a volt (black), and two volts (white dot) would be used. One possible exception would be an additional one volt dot level for a dim but still visible portion of a message or a single word.

The usual video source impedance is either 72 or 100 Ohms. Regardless of how far we travel with a composite video output, some sort of shielding is absolutely essential.

For short runs from board to board or inside equipment, tightly twisted conductors should be OK, as should properly guarded PC runs. Fully shielded cables should be used for interconnections between the TVT and the monitor or TV set, along with other long runs. As long as the total cable capacitance is less than 500 pF or so (this is around 18 feet of RG178-U

miniature coax), the receiving end of the cable need not be terminated in a 72 or 100 Ohm resistor. When terminated cable systems are in use for long line runs or multiple outputs, they should be arranged to deliver the signal levels of Fig. 1 at their output under termination. Generally, terminated cable systems should be avoided as they need extra in the way of drivers and supply power.


The exact width of the horizontal and vertical sync pulses isn't usually too important, so long as the shape and risetime of these pulses are independent of position control settings and power supply variations. One exception to this is when you're using a color receiver and a color display. Here, the horizontal sync pulse should be held closely to 5.1 microseconds, so the receiver's color burst sampling does in fact intercept a valid color burst. More on this later.

## Intentional Smear

Fig. 2 shows us a typical composite video driver using a 4066 quad analog switch. It gives us a 100 Ohm output impedance and the proper signal levels. Capacitor C1 is used to purposely reduce the video rise and fall times. It is called a smearing capacitor.

Why would we want to further reduce the bandwidth and response of a TV system that's already hurting to begin with? In the case of a quality video monitor, we wouldn't. But if we're using an ordinary run-of-the-mill TV set, particularly one using rf entry, this capacitor can

Fig. 2. Analog switch combiner generates composite video.




very much improve the display legibility and contrast. Why?

Because we are interested in getting the most legible character of the highest contrast we can. This is not necessarily the one having the sharpest dot rise and fall times. Many things interact to determine the upper video response of a TV display. These include the tuner settings and the i-f response and alignment, the video detector response, video peaking, the sound trap setting, rf cable reflections, and a host of other responses. Many of these stages are underdamped and will ring if fed too sharp a risetime input, giving us a ghosted,

shabby, or washed out character. By reducing the video bandwidth going into the system, we can move the dot matrix energy lower in frequency, resulting in cleaner characters of higher contrast.

For most TV displays, intentional smearing will help the contrast, legibility, and overall appearance. The ultimate limit to this occurs when the dots overlap and become illegible. The

Fig. 3. Block diagram of typical B and W television.



optimum amount of intentional smear is usually the value of capacitance that is needed to just close the inside of a "W" presented to the display.

## Adding a Video Input

Video inputs are easy to add to the average television set, provided you follow some reasonable cautions. First and foremost, you must have an accurate and complete schematic of the set to be modified, preferably a Sams Photofact or something similar. The first thing to check is the power supply on the set. If it has a power transformer and has the chassis properly safety isolated from the power line, it's a good choice for a TVT monitor. This is particularly

true of recent small screen, solid state portable TV sets. On the other hand, if you have a hot chassis type with one side of the power line connected to the chassis, you should avoid its use if at all possible. If you must use this type of set, be absolutely certain to use one of the safety techniques outlined later in Fig. 8.

A block diagram of a typical TV set appears in Fig. 3. UHF or VHF signals picked up by the tuner are downconverted in frequency to a video i-f frequency of 44 MHz and then filtered and amplified. The output of the video i-f is transformer coupled to a video detector, most often a small signal germanium diode. The video detector output is filtered to

remove the carrier and then routed to a video amplifier made up of one or more tubes or transistors.

At some point in the video amplification, the black and white signal is split three ways. First, a reduced bandwidth output routes sync pulses to the sync separator stage to lock the set's horizontal and vertical scanning to the video. A second bandpass output sharply filtered to 4.5 MHz extracts the FM sound subcarrier and routes this to a sound i-f amplifier for further processing. The third output is video, which is strongly amplified and then capacitively coupled to the cathode of the picture tube.

The gain of the video amplifier sets the contrast of the display, while the bias setting on the cathode of the picture tube (with respect to its grounded control grid) sets the display brightness. Somewhere in the video amplifier, further rejection of the 4.5 MHz sound subcarrier is usually picked up to minimize picture interference. This is called a sound trap. Sound traps can be a series resonant circuit to ground, a parallel resonant circuit in the video signal path, or simply part of the transformer that is picking off the sound for more processing.

The video detector output is usually around 2 volts peak to peak and usually subtracts from a white level bias setting. The stronger the signal, the more negative the swing, and the blacker the picture. Sync tips are blacker than black, helping to blank the display during retrace

Fig. 4 shows us the typical video circuitry of a transistor black and white television. Our basic circuit consists of a diode detector, a unity gain emitter follower, and a variable gain video output stage that is capacitively coupled to the picture tube. The cathode bias sets the brightness, while the video gain sets the contrast. Amplified signals for sync and sound are removed from the collector of the video driver by way of a 4.5 MHz resonant transformer for the sound and a low pass filter for the sync. A parallel resonant trap set to 4.5 MHz eliminates sound interference. Peaking coils on each stage extend the bandwidth by providing higher impedances

and thus higher gain to high frequency video signals.

Note particularly the biasing of the video driver. A bias network provides us with a stable source of 3 volts. In the absence of input video, this 3 volts sets the white level of the display, as well as establishing proper bias for both stages. As an increasing signal appears at the last video output transformer, it is negatively rectified by the video detector, thus lowering the 3 volts proportionately. The stronger the signal, the blacker the picture. Sync will be the strongest of all, giving us a blacker than black bias level of only one volt.

The base of our video driver has the right sensitivity we need for video entry,

accepting a maximum of a 2 volt peak to peak signal. It also has the right polarity, for a positive going bias level means a whiter picture. But, an unmodified set is already biased to the white level, and if we want to enter our own video, this bias must be shifted to the black level.

We have a choice in any TV of direct or ac coupling of our input video. Direct coupling is almost always better as it eliminates any





Fig. 4. Typical video circuitry of transistor B and W TV set.

Fig. 5. Direct coupled video uses 1.2 volt offset of Darlington transistor as bias

shading effects or any change of background level as additional characters are added to the screen. Fig. 5 shows how we can direct couple our video into a transistor black and white set. We provide a video input, usually a BNC or a phono iack, and route this to a PNP Darlington transistor or transistor pair, borrowing around 5 mils from the set's +12 volt supply. This output is routed to the existing video driver stage through a SPDT switch that either picks the video input or the existing video detector and bias network.

The two base-emitter diode drops in our Darlington transistor add up to a 1.2 volt positive going offset; so, in the absence of a video input or at the base of a sync tip, the video driver is biased to a blacker than black sync level of 1.2 volts. With a white video input of 2 volts, the video driver gets biased to its usual 3.2 volts of white level. Thus, our input transistor provides just the amount of offset we need to match the white and black bias levels of our video driver. Note that the old bias network is on the other side of the switch and does nothing in the video position.

Two other ways to offset our video input are to use two ordinary transistors connected in the Darlington configuration, or to use one transistor and a series diode




to pick up the same amount of offset, as shown in Fig. 5. If more or less offset is needed, diodes or transistors can be stacked up further to pick up the right amount of

The important thing is that the video driver ends up with the same level for white bias and for black bias in either position of the switch.

Ac or capacitively coupled video inputs should be avoided. Fig. 6 shows a typical circuit. The TV's existing bias network is lowered in voltage by adding a new parallel resistor to ground to give us a voltage that is 0.6 volts more positive than the blacker than black sync tip voltage. For instance, with a 3 volt white level, and


Fig. 6. Ac coupled video needs shift of bias to black level plus a clamping diode



2 volt peak to peak video, the sync tip voltage would be 1 volt; the optimum bias is then 1.6 volts. Input video is capacitively coupled by a fairly large electrolytic capacitor in parallel with a good high frequency capacitor. This provides for a minimum of screen shading and still couples high frequency signals properly. A clamping diode constantly clamps the sync tips to their bias value, with the 0.6 volt drop of this diode being taken out by the extra 0.6 volts provided for in the bias network. This clamping diode automatically holds the sync tips to their proper value, regardless of the number of white dots in the picture. Additional bypassing of the bias network by a large electrolytic may be needed for proper operation of the clamping diode, as shown in Fig. 6. Note that our bias network is used in both switch positions - its level is shifted as needed for the direct video input.

Tube type sets present about the same interface problems as the solid state versions do. Fig. 7 shows a typical direct coupled tube interface. In the unmodified

Fig. 7. Direct coupled video added to tube type B and W television.



circuit, the white level is zero volts and the sync tip black level is minus two volts. If we can find a negative supply (scarce in tube type circuits), we could offset our video in the negative direction by two volts to meet these bias levels.

Instead of this, it is usually possible to self bias the video amplifier to a cathode voltage of +2 volts. This is done by breaking the cathode to ground connection and adding a small resistor (50 to 100 Ohms) between cathode and ground to get a cathode voltage of +2 volts. Once this value is found, a heavy electrolytic bypass of 100 microfarads or more is placed in parallel with the resistor. Switching then grounds the cathode in the normal rf mode and makes it +2 volts in the video entry mode.

In the direct video mode, a sync tip grounded input presents zero volts to the grid, which is self biased

minus two volts with respect to the cathode. A white level presents +2 volts to the grid, which equals zero volts grid to cathode.

Should there already be a self bias network on the cathode, it is increased in value as needed to get the black rather than white level bias in the direct video mode.

## Hot Chassis Problems

There is usually no shock hazard when we use clip-on rf entry or when we use a direct video jack on a transformer-powered TV. A very severe shock hazard can exist if we use direct video entry with a TV set having one side of the

power line connected to the chassis. Depending on which way the line cord is plugged in, there is a 50-50 chance of the hot side of the power line being connected directly to the chassis.

Hot chassis sets, particularly older, power hungry tube versions, should be avoided entirely for direct video entry. If one absolutely must be used, some of the suggestions of Fig. 8 may ease the hazard. These include using an isolation transformer, husky back-to-back filament transformers, three wire power systems, optical coupling of the video input,

and total package isolation. Far and away the best route is simply never to attempt direct video entry onto a hot chassis TV.

#### Making the Conversion

Fig. 9 sums up how we modify a TV for direct video entry. Always have a complete schematic on hand, and use a transformer style TV set if at all possible. Late models, small screen, medium to high quality solid state sets are often the best display choice. Avoid using junk sets, particularly very old ones. Direct coupling of video is far preferable to ac capacitor coupling. Either method has to maintain the black and white bias levels on the first video amplifier stage. A shift of the first stage quiescent bias from normally white to normally black is also a must. Use short, shielded leads between the video input jack and the rest of the circuit. If a changeover switch is used, keep it as close to the rest of the video circuitry as you possibly can.

## Extending Video and Display Bandwidth

By using the direct video input route, we eliminate any bandwidth and response restrictions of an rf

modulator, the tuner, video i-f strip, and the video detector filter. Direct video entry should bring us to a 3 MHz bandwidth for a color set and perhaps 3.5 MHz for a black and white model, unless we are using an extremely bad set. The resultant 6 to 7 million dot per second rate is adequate for short character lines of 32, 40, and possibly 48 characters per line. But the characters will smear and be illegible if we try to use longer line lengths and premium (lots of dots) character generators on an ordinary TV. Is there anything we can do to the set to extend the video bandwidth and display response for these longer line lengths?

In the case of a color TV, the answer is probably no. The video response of a color set is limited by an essential delay line and an essential 3.58 MHz trap. Even if we were willing to totally separate the chrominance and luminance channels, we'd still be faced with an absolute limit set by the number of holes per horizontal line in the shadow mask of the tube. This explains why video color displays are so expensive and so rare. Later on, we'll look at what's involved in adding color to the shorter line lengths.

With a black and white TV, there is often quite a bit

Fig. 8. Getting Around a Hot Chassis Problem.

Hot chassis problems can be avoided entirely by using only transformer-powered TV circuits or by using clip-on rf entry. If a hot chassis set must be used, here are some possible ways around the problem:

### 1. Add an isolation transformer.

A 110 volt to 110 volt isolation transformer whose wattage exceeds that of the set may be used. These are usually expensive, but a workable substitute can be made by placing two large surplus filament transformers back to back. For instance, a pair of 24 volt, 4 Amp transformers can handle around 100 Watts of set.

## 2. Use a three wire system with a solid ground.

Three prong plug wiring, properly polarized, will force the hot chassis connection to the cold side of the power line. This protection is useful only when three wire plugs are used in properly wired outlets. A severe shock hazard is reintroduced if a user elects to use an adaptor or plugs the system into an unknown or improperly wired outlet. The three wire system should NOT be used if anyone but yourself is ever to use the system.

## 3. Optically couple the input video.

Light emitting diode-photocell pairs are low in cost and can be used to optically couple direct video, completely isolating the video input from the hot chassis. Most of these optoelectronic couplers do not have enough bandwidth for direct video use; the Litronix IL-100 is one exception. Probably the simplest route is to use two separate opto-isolators, one for video and one for sync, and then recombine the signals inside the TV on the hot side of the circuit.

## 4. Use a totally packaged and sealed system.

If you are only interested in displaying messages and have no other input/output devices, you can run the entire circuit hot chassis, provided everything is sealed inside one case and has no chassis-to-people access. Interface to teletypes, cassettes, etc., cannot be done without additional isolation, and servicing the circuit presents the same shock hazards that servicing a hot chassis TV does.

we can do to present long lines of characters, depending on what set you start out with and how much you are willing to modify the set.

The best test signal you can use for bandwidth extension is the dot matrix data you actually want to display, for the frequency response, time delay, ringing, and overshoot all get into the act. What we want to end up with is a combination that gives us reasonably legible characters.

A good oscilloscope (15 MHz or better bandwidth) is very useful during bandwidth extension to show where the signal loses its response in the circuit. At any time during the modification process, there is usually one response bottleneck. This, of course, is what should be attacked first. Obviously the better a TV you start with, the easier will be the task. Tube type gutless wonders, particularly older ones, will be much more difficult to work with than with a modern, small screen, quality solid state portable.

Several of the things we can do are watching the control settings, getting rid of the sound trap, minimizing circuit strays, optimizing spot size, controlling peaking, and shifting to higher current operation. Let's take a look at these in turn.

## Control Settings

Always run a data display at the lowest possible contrast and using only as much brightness as you really need. In many circuits, low contrast means a lower video amplifier gain, and thus less of a gain-bandwidth restriction.


## Eliminate the Sound Trap

The sound trap adds a notch at 4.5 MHz to the video response. If it is eliminated or switched out of the circuit, a wider video bandwidth automatically

Fig. 9. How to Add a Direct Video Input to a TV Set.


- Get an accurate and complete schematic of the set — either from the manufacturer's service data or a Photofact set. Do not try adding an input without this schematic!
- 2. Check the power supply to see if a power transformer is used. If it is, there will be no shock hazard, and the set is probably a good choice for direct video use. If the set has one side of the power line connected to the chassis, a severe shock hazard exists, and one of the techniques of Fig. 8 should be used. Avoid the use of hot chassis sets.
- 3. Find the input to the first video amplifier stage. Find out what the white level and sync level bias voltages are. The marked or quiescent voltage is usually the white level; sync is usually 2 volts less. A transistor TV will typically have a +3 volt white level and a +1 volt sync level. A tube type TV will typically have a zero volt white level and a -2 volt sync level.
- Add a changeover switch using minimum possible lead lengths. Add an input connector, either a phono jack or the premium BNC type connector. Use shielded lead for interconnections exceeding three inches in length.
- 5. Select a circuit that couples the video and biases the first video amplifier stage so that the white and sync levels are preserved. For transistor sets, the direct coupled circuits of Fig. 5 may be used. For tube sets, the circuit of Fig. 7 is recommended. Avoid the use of ac coupled video inputs as they may introduce shading problems and changes of background as the screen is filled.
- 6. Check the operation. If problems with contrast or sync tearing crop up, recheck and adjust the white and sync input levels to match what the set uses during normal rf operation. Note that the first video stage must be biased to the white level during rf operation and to the sync level for direct video use. The white level is normally two volts more positive than the sync level.

Fig. 10. Removing the sound trap can extend video bandwidth.






(b) Parallel resonant trap -







results. Fig. 10 shows us the response changes and the several positions for this trap. Generally, series resonant traps are opened and parallel resonant traps are shorted or bypassed through suitable switching or outright elimination. The trap has to go back into the circuit if the set is ever again used for ordinary program reception. Sometimes simply backing the slug on the trap all the way out will improve things enough to be useful.

## Minimizing Strays

One of the limits of the video bandwidth is the stray capacitance both inside the video output stage and in the external circuitry. If the contrast control is directly in the signal path and if it has long leads going to it, it may be hurting the response. If you are using the TV set exclusively for data display, can you rearrange the control location and simplify and shorten the video output to picture interconnections?


### Additional Peaking


Most TV sets have two peaking networks. The first of these is at the video detector output and compensates for the vestigial sideband transmission signal that makes sync and other

low frequency signals double the amplitude of the higher frequency ones. The second of these goes to the collector or plate of the video output stage and raises the circuit impedance and thus the effective gain for very high

VIDEO OUTPUT

Fig. 11. Adjusting the peaking coil can extend video response.





can alter this second network to favor dot presentations. Fig. 11 shows a typical peaking network and the effects of too little or too much peaking. Note that the stray capacitance also enters into the peaking, along with the video amplifier output capacitance and the picture tube's input capacitance. Generally, too little peaking will give you low contrast dots, while too much will give you sharp dots, but will run dots together and shift the more continuous portions of the characters objectionably. Peaking is changed by increasing or decreasing the series inductor from its design value.

frequencies. Sometimes you

### Running Hot

Sometimes increasing the operating current of the video output stage can increase the system bandwidth - IF this stage is in fact the limiting response, IF the power supply can handle the extra current, IF the stage isn't already parked at its gain-bandwidth peak, and IF the extra heat can be gotten rid of without burning anything up. Usually, you can try adding a resistor three times the plate or collector load resistor in parallel, and see if it increases bandwidth by 1/3. Generally, the higher the current, the wider the bandwidth, but watch

carefully any dissipation limits. Be sure to provide extra ventilation and additional heatsinking, and check the power supply for unhappiness as well. For major changes in operating current, the emitter resistors and other biasing components should also be proportionately reduced in value.

#### Spot Size

Even with excellent video bandwidth, if you have an out-of-focus, blooming, or changing spot size, it can completely mask character sharpness. Spot size ends up the ultimate limit to resolution, regardless of video bandwidth.

Once again, brightness and contrast settings will have a profound effect, with too much of either blooming the spot. Most sets have a focus jumper in which ground or a positive voltage is selected. You can try intermediate values of voltage for maximum sharpness. Extra power supply filtering can sometimes minimize hum and noise modulation of the spot.

Anything that externally raises display contrast will let you run with a smaller beam current and a sharper spot. Using circularly polarized filters, graticule masks, or simple colored filters can

Fig. 12. Contrast Enhancing

Circularly polarized filters:

Polaroid Corp. Cambridge MA 02139

Anti-reflection filters:

Panelgraphic Corp. 10 Henderson Dr West Caldwell NJ 07006


Light control film:

3M Visual Products Div. 3M Center St. Paul MN 55101

Acrylic plexiglas filter sheets:

Rohm and Haas Philadelphia PA 19105

Fig. 13. Standard rf interface levels. Impedance =  $300\Omega$ . Carrier frequency per Fig. 14.



minimize display washout from ambient lighting. Fig. 12 lists several sources of material for contrast improvement. Much of this is rather expensive, with pricing from \$10 to \$25 per square foot being typical. Simply adding a hood and positioning the display away from room lighting will also help and is obviously much cheaper.

## Direct Rf Entry

If we want the convenience of a "free" display, the freedom from hot chassis problems, and "use it anywhere" ability, direct rf entry is the obvious choice. Its two big limitations are the need for FCC type approval, and a limited video bandwidth that in turn limits the number of characters per line and the number of dots per character.

An rf interface standard is shown in Fig. 13. It consists of an amplitude modulated carrier of one of the standard television channel video frequencies of Fig. 14. Channel 2 is most often used

with a 55.250 MHz carrier frequency, except in areas where a local commercial Channel 2 broadcast is intolerably strong. Circuit cost, filtering problems, and stability problems tend to increase with increasing channel number.

The sync tips are the strongest part of the signal, representing 100% modulation, often something around 4 millivolts rms across a 300 Ohm line. The black level is 75% of the sync level, or about 3 millivolts for 4 millivolt sync tips. White level is less than 10% of maximum. Note that the signal is weakest when white and strongest when sync. This is the exact opposite of the video interface of Fig. 1.

Rf modulators suitable for clip-on rf entry TV typewriter use are called Class 1 TV Devices by the FCC. A Class 1 TV device is supposed to meet the rules and regulations summarized in

diagram of the essential parts of a TV modulator. We start

Fig. 14. Television Picture Carrier Frequencies.

Channel 2	 	55.25	MHz
Channel 3	 	61.25	MHz
Channel 4	 	67.25	MHz
Channel 5	 	77.25	MHz
Channel 6	 	83.25	MHz

Fig. 15. FCC Regulations on Class 1 TV Devices. More complete information appears in subpart H of Part 15 and subpart F of Part 2 of the Federal Communications Commission Rules and Regulations. It is available at many large technical libraries.

A Class 1 TV device generates a video modulated rf carrier of a standard television channel frequency. It is directly connected to the antenna terminals of the TV set.

The maximum rms rf voltage must be less than 6 millivolts using a 300 Ohm output line.
The maximum rf voltage on

any frequency more than 3 MHz away from the operating channel must be more than 30 dB below the peak in-channel output voltage.

An antenna disconnect switch of at least 60 dB attenuation must be provided.

No user adjustments are permitted that would exceed any

of the above specifications.


Residual rf radiation from case, leads and cabinet must be less than 15 microvolts per meter.
A Class 1 TV device must not

interfere with TV reception.

Type approval of the circuit is required. A filing fee of \$50 and an acceptance fee of \$250 is

involved.

Fig. 16. Block diagram of rf modulator.



with a stable oscillator tuned to one of the Fig. 14 frequencies. A crystal oscillator is a good choice, and low cost modules are widely available. The output of this oscillator is then amplitude modulated. This can be done by changing the bias current through a silicon small signal diode. One milliampere of bias current makes the diode show an ac and rf impedance of 26 Ohms. Half a mil will look like 52 Ohms, and so on. The diode acts as a variable resistance attenuator in the rf circuit, whose bias is set and changed by the video circuit.

Since diode modulators are non-linear, we can't simply apply a standard video signal to them and get a standard rf signal out. A differential amplifier circuit called a video slicer may be used to compensate for this non-linearity. The video slicer provides three distinct currents to the diode modulator. One of these is almost zero for the white level, while the other two provide the black and sync levels. A contrast control that sets the slicing level lets you adjust the sync tip height with respect to the black level. The video slicer also minimizes rf getting back into the video. An attenuator to reduce the size of the modulated signal usually follows the diode modulator.

An upper side band filter removes most of the lower sideband from the AM modulated output, giving us a

vestigial sideband signal that stays inside the channel band limits. This same filter eliminates second harmonic effects and other spurious noise. The filter's output is usually routed to an antenna disconnect switch and the TV's antenna terminals. A special switch is needed to provide enough isolation.

Some of the actual circuitry involved is shown in Fig. 17. The video slicer consists of a pair of high gain, small signal NPN transistors, while the oscillator is a commercially available module.

Rf entry systems always must be direct coupled to the antenna terminals of the set and should never provide any more rf than is needed for a minimum snow-free picture. They should be permanently tuned to a single TV channel. Under no circumstances should an antenna or cable service hookup remain connected to the set during TVT use, nor should radiation rather than a direct rf cable connection ever be used.


## Color Techniques

We can add a full color capability to a TV typewriter system fairly easily and cheaply — provided its usual black and white video dot rate is low enough in frequency to be attractively displayed on an ordinary color TV. Color may be used to emphasize portions of a message, to attract attention, as part of an electronic game, or as obvious added value to a graphics display. Color techniques work best on TV typewriter systems having a horizontal frequency very near 15,735 Hertz.

All we basically have to do is generate a subcarrier sine wave to add to the video output. The phase of this subcarrier (or its time delay) is shifted with respect to what the phase was immediately after each horizontal sync pulse to generate the various colors.

Fig. 18 shows us the differences between normal color and black and white operation. Black and white baseband video is some 4 MHz wide and has a narrow 4.5 MHz sound subcarrier. The video is amplitude modulated, while the sound is narrow band frequency

Fig. 17. Channel two oscillator, modulator, video slicer and attenuator. R sets output level.



## Fig. 18. Differences between color and black and white spectra.

#### (a) Black and white - baseband video.





(b) Black and white - Channel two rf.


#### (c) Color - baseband video.

modulated. This translates up to a 6 MHz rf channel with a vestigial lower sideband as shown in Fig. 18(b).

To generate color, we add a new pilot or subcarrier at a magic frequency of 3.579545 MHz — see Fig. 18(c). What was the video is now called the luminance, and is the same as the brightness in a black and white system. The new subcarrier and its modulation is called the chrominance signal and determines what color gets displayed and how saturated the color is to be.

Since the black and white information is a sampled data system that is scanned at the vertical and horizontal rates, there are lots of discrete holes in the video spectrum that aren't used. The color subcarrier is designed to stuff itself into these holes (exactly in a NSTC color system, and pretty much in a TVT display). Both chrominance and luminance signals use the





(d) Color - Channel two rf.

same spectral space, with the one being where the other one isn't, overlapping comb style.

The phase or relative delay of the chrominance signal with respect to a reference determines the instantaneous color, while the amplitude of this signal with respect to the luminance sets the saturation of the color. Low amplitudes generate white or pastel shades, while high amplitudes of the chrominance signal produce saturated and deep colors.

At least eight cycles of a reference or burst color phase are transmitted immediately following each horizontal sync pulse as a timing reference, as shown in Fig.

19. The burst is around 25% of maximum amplitude, or about the peak to peak height of a sync pulse.

The TV set has been trained at the factory to sort all this out. After video detection, the set splits out the chrominance channel with a bandpass amplifier and then synchronously demodulates it with respect to an internal 3.58 MHz reference. The phase of this demodulation sets the color and the amplitude sets the saturation by setting the

ratios of electron beam currents on the picture tube's red, blue and green guns.

Meanwhile, the luminance channel gets amplified as brightness style video. It is delayed with a delay line to make up for the time delay involved in the narrower band color processing channel. It is then filtered with two traps the 4.5 MHz sound trap, and a new trap to get rid of any remaining 3.58 MHz color subcarrier that's left. The luminance output sets the overall brightness by modulating the cathodes of all three color guns simultaneously.

Just after each horizontal sync pulse, the set looks for the reference burst and uses this reference in a phase

Fig. 19 Adding a color reference burst to the back porch of the horizontal sync pulses.




Fig. 20. Colors Are Generated by Delaying or Phase Shifting the Burst Frequency.

Color	Approximate Phase	Approximate Delay	
Burst	o°	0	
Yellow	15°	12 nanoseconds	
Red	75°	58 nanoseconds	
Magenta	135°	105 nanoseconds	
Blue	195°	151 nanoseconds	
Cyan	255°	198 nanoseconds	
Green	315°	244 nanoseconds	

detector circuit to keep its own 3.58 MHz reference locked to the version being transmitted.

Fig. 20 shows us the phase angles related to each color with respect to the burst phase. It also shows us the equivalent amount of delay we need for a given phase angle. Since we usually want only a few discrete colors, it's far easier to digitally generate colors simply by delaying the reference through gates or buffers, rather than using complex and expensive analog phase shift methods.

Strictly speaking, we should control both the chrominance phase and amplitude to be able to do both pastel and strongly saturated colors. But simply keeping the subcarrier amplitude at the value we used for the burst — around 25% of video amplitude— is far simpler and will usually get us useful results.

A circuit to add color to a TV typewriter is shown in Fig. 21. A 3.579545 MHz crystal oscillator drives a string of CMOS buffers that make up a digital delay line. The output delays caused by the propagation delay times in each buffer can be used as

is, or can be trimmed to specific colors by varying the supply voltage.

The reference phase and the delayed color outputs go to a one-of-eight data selector. The data selector picks either the reference or a selected color in response to a code presented digitally to the three select lines. The logic that is driving this selector must return to the

reference phase position (000) immediately before, during and for a minimum of a few microseconds after each horizontal sync pulse. This gives the set a chance to lock and hold onto the reference color burst.

The chrominance output from the data selector should be disabled for the duration of the sync pulses and any time a white screen display is

wanted. The output chrominance signal is RC filtered to make it somewhat sinusoidal. It's then cut down in amplitude to around one-quarter the maximum video white level and is capacitively coupled to the 100 Ohm video output of Fig. 2 or otherwise summed into the video or rf modulator circuitry. For truly dramatic color effects, the amplitude and delay of the chrominance signal can be changed in a more complex version of the same circuit.

More information useful in solving television interface appears in the Television Engineering Handbook, by Donald Fink, and in various issues of the IEEE Transactions on Consumer Electronics.

Fig. 21. Color subcarrier generator. Hex buffer used as delay line. Use supply voltage variation on 4050 to trim colors.

